



Operation Manual of MS horizontal injectionmolding machine control system

Welcome to use Our Injection Molding Machine Control System

Safety Cautions

(Please read it before installation)



Danger

1. When the exterior power supply is abnormal or the control system breaks down, make sure the safety circuit is installed outside the control system in order to make the entire system work safely.
2. When abnormal situations occur, such as the control system unable to test the input/output, the output can not be controlled; in order to make the machine operate safely, for the output signal related to major accident, please design the exterior safety circuit or protection device.
3. The emergency door safety device is the core safety part of the injection molding machine. Make sure related safety protection devices for machine and oil line are added outside.



Cautions

1. Others except the trained and qualified professional technicians are not allowed to install and maintain this system.
2. When a valuable or large die is used, the travel control method must be adopted to use the neutron; otherwise, the control system can not guarantee the safety of the die.

Line of MS
Operator's Manual

System Configuration & Installation 1

Button Operation specification 5

*Explanation of the Parameter/
Function Setting* 14

Production management 46

*Explanation of the System
Debugging and Setting* 58

Input/output State Detection 76

Reference & Appendices 81

All copyrights are reserved, any duplication without the prior authorization shall be forbidden.

Contents

Chapter 1 System Configuration & Installation

- 1. System Configuration & Remarks.....p1
- 2. Features of the MC800AM Control System.....p1
- 3. Installation and Debugging of Computer Control System.....p2

Chapter 2 Specifications of the Button-Pressed Operations

- 1. Figure of Keyboard of the Operation Panel (See the figure below).....p5
- 2. Explanation of the Functional Keys.....p6
- 3. Explanation of the Parameter Setting button.....p8
- 4. Cursor Key.....p9
- 5.Operation Mode Selection Key.....p9
- 6. Electrothermal ON/OFF key and Motor ON/OFF key.....p9
- 7. Manual Operation Keys.....p10
- 8. Setting Scope of Numeric Items.....p13

Chapter 3: Descriptions on setting parameters/functions

- 1. The main control panel shown while turning on.....p14
- 2. The descriptions on display.....P15
- 3. Descriptions on alarm mode.....P16
- 4. Descriptions on operation/prompt mode.....P17
- 5 Setting for celerity information.....P18
- 6 Setting for mold close information.....p19
- 7. Set mold open information.....p20
- 8. Set the plastic injector information.....p21
- 9. Set the hold pressure information.....p22
- 10. The feed/suck back/cooling information.....p23
- 11. Set the auto clear setup information.....p24
- 12. Set the nozzle information.....p25
- 13. Set the mold adjusting information.....p26
- 14. Set the ejector forward information.....p27
- 15. Set core AB information.....p28
- 16. Set core CD information.....p29
- 17. Set blowing information.....p30
- 18. Set time/count information.....p31
- 19. Set temperature information.....p32
- 20. Hot runner temp setup information information.....P33
- 21. Set warm-up information.....P34
- 22. Set mold data information.....P35
- 23. Set Amendment history information.....P37
- 24. Set special parameters information.....P38
- 25. Set Ethernet information.....P39
- 26. Set MES-Injection Workshop Management system (Optional)P43

Chapter 4 production management

1. Set production Information	p46
2. The output statistics information	p47
3. SPC Track record Page	p48
4. The Incident track back page	p49
5. The injection curve page	p50
6. The servo -real time curve page	p51
7. The History curve page of servo page	p52
8. the temperature tracking curve page	p53
9. the temperature monitor page	p54
10. the injection speed curve page	p55
11. USB setting page (for options)	p56

Chapter 5 Instructions for the System Commissioning Settings

1. Engineer Setting Page	p58
2. Delay Setting Page	p59
3. Pressure/Flux Slope Setting Page	p60
4. Pressure Pre-Adjustment Page	p61
5. Flux Pre-Adjustment Page	p62
6. Back Pressure Pre-Adjustment Page	p63
7. Electronic Ruler/ Pressure Setting Inspection Page	p64
8. Special Function Options Page	p65
9. Servo Driver monitor Setup Page	p70
10. Servo Driver Setup Page	p71
11. Standby Function Setting Page	p72
12. Programmable Standby Function Page	p73
13. Temperature Parameter Page	p74
14. Machine No./ Production-Factory Value Setting Page	p75

Chapter 6 Input/Output Mode Inspection

1. Alarm history page	p76
2. Input Inspection Page	p77
3. Key inspection Page	p78
4. Output Inspection Page	p79

Reference & Appendices

Appendix 1: MS210 keyboard installation dimension Layout	p81
Appendix 2: MS220/250 keyboard installation dimension Layout	p82
Appendix 3: MS260 keyboard installation dimension Layout	p83
Appendix 4: External dimensions for power supply case and transformer	p84
Appendix 5: MS500 system drawing	p86
Appendix 6: MS300 input and output Wiring Diagram	p87
Appendix 7: MS500 input and output Wiring Diagram	p88
Appendix 8: MS700 input and output Wiring Diagram	p89
Appendix 9: Motor Electric-Heating Wiring Diagram (for reference only)	p90
Appendix 10: Introduction of new type of patent double channel compensation linear sensor	p91
Appendix 11: Magnetic suspension displacement sensor	p92
Appendix 12: Product selection table	p94
Appendix 13: Product Guarantee Terms	p95

Chapter 1 System Configuration & Installation

1. System Configuration & Remarks

No.	Code	Content	NO	Remarks
1.Host Computer	MS300		1 Set	Optional
	MS500		1 Set	
	MS700		1 Set	
2.Keyboard	MS210 7.0inch	For specifications please refer to appendix 12 Model selection chart	1 Set	Optional
	MS220 7.0inch		1 Set	
	MS250 8.0inch		1 Set	
	MS260 10.2inch		1 Set	
3.Power pack	PW350	350W	1 Set	
4.Message cable	DB-15F	1 To 8 meter optional	1 Set	


2. Characteristics of MC800AM Control System

- ▶ The system has bright LCD display
- ▶ The system adopts two CPU design with fast operating speed, precise control and high stability.
- ▶ It has the real time function to display time and date in real time.
- ▶ With 999 groups of mode data storage, it may enter the mode description and real-time operating help in Chinese and English.
- ▶ The password setting and data locking can prevent the operators from changing the established data arbitrarily to influence the quality of products.
- ▶ There are multiple languages for your choice that display dynamically in real time.
- ▶ Packing modulus setting function for 8-digit output may set the packing modulus.
- ▶ Various self-plugging and tein type programs are applicable for the self-plugging and tein control in different types.
- ▶ PID with self temperature control has (6+1) sections of temperatures.
- ▶ Temperature may be preset a week in advance to enable more convenient operation.
- ▶ Failure Self-detection functions, alarm display and voice prompt
- ▶ Input and output are done by the optically coupled circuit to isolate the interference of the external circuitry.
- ▶ 4-channel of standard D/A output, max current output is 3 A (standard: 1A), 2-channel of PWM output.
- ▶ The output value of pressure, speed, current can have real-time dynamic observation, and it is not necessary to install another ammeter
- ▶ 8-channel of double-linear scale, 8-channel of single linear scale, 4-channel of maglev ruler,
- ▶ 4-channel of pressure detection.
- ▶ Presetting of the voltage and runoff values, proportional valve available for the products in all brands and better linear proportion.
- ▶ The management of 255 machine production is by a host networking computer, It can accurately
- ▶ Statistics each machine production state and produce data type, so it is convenient to manage.

3. Installation and Debugging of Computer Control System

3. 1 Cautions upon Installing the Control System

The design of control system is simple and easy, only one 15-core shielding cable connecting the keyboard and host computer shell with flexible and handy installation and connection. The sketch map for installation is shown as follows:




control box equipment outfit (for reference only)

- (1) Upon installing the host control box, adopt the enclosed distribution cabinet at the first choice. It shall be fixed in the well-ventilized, greaseproof and dustproof conditions equipped with a fan and dustproof. The distribution box shall be stored under 50degree.
- (2) Upon fixing the host computer and power pack, please keep the interconnecting partssuch as all AC connectors and transformers as far away from each other as possible to prevent the electric wave interference from the electronic grid.
- (3) All electric wires and shielding wires shall not be cut off, lengthened or curtailed arbitrarily. You should use the electricwires and shielding wiresprovided by this companyto prevent from influencing the reliability andnormal operation of thecontrol system.
- (4) The shell of flame couple shall adopt the shielding wire. When the outer shielding of all flame couples adopts the thermal couple reticles, the reticle and machines shall be well grounded and connected to the ground with the earthing resistance below 4ohm.
- (5) Upon wiring, separate the high and low pressure line from the computer control line as much as possible, do not bind all electrical wires together to prevent the interference from affecting the reliable operation of control system.
- (6) Upon fixing the keyboard and 15-core communication connections of the host computer, you shall press and tweakwith force to preventthe poor connection fromaffecting the reliable operation of control system.
- (7) Pay special attention to the oil valve outlet public port YCOM, it shall be connected well to prevent the computer from inputting while having the phenomenon of oil valve having no motion.


3. 2 Inspection of the Control System


- (1) After installation completed, carry out an over all inspection if all connection lines are well fixed including the switching power supply, host computer shell, electrothermal output line and the thermal couple of keyboard.
- (2) After the line inspection completed, carry out an electric connection inspection. First take Out the 11-digital output line plug of the DC power supply outlet port, namely the power pack PW450, And then power on to examine and measure if the voltage is the same as the nominal values and observe if the output indicator on the power pack is normal.
- (3) Power off after the measurement completed, insert the DC power supply to input to the plug of host computer shell. After power-on again for inspection, LCD on the keyboard will display the normal state of the main page. Revolve on the emergency stop switch to check if the RUN indicator on the host computer shell turns on. When it turns on, it indicates that the system can work soundly.

3. 3 Setting of the Control System

- (1) After the system having shown normal operating state, press  button on the monitor page to adjust color and comparison.





- (2) To conduct the parameter setting and memory testing, press  button to select a group

of module numbers and then set data in all screens. Press  button to save data. Disconnect the power and connect it again after a few time, the system will automatically call the data of module numbers saved by you. In case of they are correct, it indicates that the memory is all right.

- (3) Afterwards, set the data in all relevant data (please see Chapter III Explanation of the Parameter Setting for the detailed operations). Upon setting in the first time, set the pressure and speed as little as possible and then after all movements come normally, gradually increase the values to normal parameters to prevent from damaging the mechanical performances.
- (4) After all parameter set, save them and carefully inspect if all input and output points are normal. Carry out an overall inspection of the alarm system, including the front and back safety doors. The wire of safety doors shall be connected as stated in the following figure.


Safety Door 1





Safety Door Wiring Diagram (for reference only)

Safety Door 2



Safety Door Wiring Diagram (for reference only)

★ Safety Doors * Special Explanation:












When X00=ON/X15=OFF or X00=OFF/X15=ON closing/opening the doors, or in case of other abnormal conditions, the system will issue an alarm 2 seconds later for Safety Door Failure and simultaneously terminate all operating output. In the semi-automatic mode, the condition for opening/ closing the safety doors is that the time from LS1, LS2, LS3, LS4 all turn [OFF] to all turn [ON] is more than 0.5 as valid in order to prevent the twitter of safety door switches from causing error operation.












Chapter 2 Explanation of the Key Operations

1. Figure of Keyboard on the Operation Panel (See the figure below)



2. Explanation of the Functional Keys

<i>Keys</i>	<i>Usage</i>
 開鎖模 M.PLT	Enter into page for mould opening & mould clamping setting
 射出 INJECTION	Enter into page for ejection & pressure maintaining setting
 儲料 FEEDING	Enter into page for feeding, shoot retreat & automatic material clearing setting
 座臺/調模 NOZZ/ADJ.	Enter into page for seat stand & mould adjustment setting
 托模/中子 EJE/CORE	Enter into page for ejector, self-plugging and huff setting.
 時間 TIME	Enter into page to set timing and counting.
 溫度 TEMP.	Enter into page for temp pre-heating & temp monitor setting.
 資料 DATUM	Enter into page for mould ,Datum modification setting
 快速設定 CELERITY SET	Enter into pages for celerity one、two setting
 監視 MONITOR	Return to monitor page at anytime.
 幫助 HELP	Enter into real time help page under current status.





<i>Keys</i>	<i>Usage</i>
	Enter into page of USB setting
	Enter into page to set alarm
	Enter into page to injection, servo temp curve
	Enter into pages to set production data & SPC Tracking
	For entering into MES production management page
	This function only limit to panel of Mk360. Current page can be printed on pressing this key.
	This function only limit to panel of Mk360. When cursor moves to such as the time setup location, 1 will be automatically increased with each pressing on this key.
	This function only limit to panel of Mk360. When cursor moves to such as the time setup location, 1 will be automatically reduced with each pressing on this key
	This function only limit to panel of Mk360. Press this key is equal to move cursor to [Enter] while in log in status and then press the enter key
	This function only limit to panel of Mk360. When cursor moves to such as mould name modification, press this key to switch Chinese/English input method
	This function only limit to panel of Mk360. Press this key is equal to move cursor to [Cancel] while in log in status and then press the cancel key .

3. Explanation of the Parameter Setting







0-9 numeric keys are used for data input in the data settingpage. When electric lock is in “OFF” State, these ten numbers are locked to ensure the data will not be changed arbitrarily. In the meanwhile, there are 26English letters and special symbols respectively on 0-9 numeric keys used for the input ofChinese and English letters as well as the machine serial number. [Delete] key is used to delete the error words during entering the parameters and serial numbers. [Input] key is used to select the functions during function Selection and used to confirm during item confirmation.

4. Cursor Key

Keys	Usage
	Skip key, pressing it will skip the cursor to the upper line
	Escape key, pressing it will move the cursor to the left
	Escape key, pressing it will move the cursor to the right
	Skip key, pressing it will skip the cursor to the lower line

5. Operation Mode Selection Key

Keys	Usage	Remarks
	Pressing this key will enter the system into manual state.	There is an indicator on the left upper of all keys. Pressing any key will turn on this indicator, indicating the system is in this state. Every time the computer is started, the default state of system is manual operation. In case of the temperature has not reached the set value, the system is impossible to perform semi-automatic, semi-automatic and time automatic operations. The indicator will not turn on when the semi-automatic, semi-automatic and time automatic operation key pressed till the temperature reaches the set value.
	Pressing this key will enter the system into semi-automatic operation	
	Pressing this key will enter the system into semi-automatic operation	
	Pressing this key will enter the system into time-automatic operation	











6. Electro thermal ON/OFF key










and Motor ON/OFF key

















In the manual mode, press the key once and the indicator at the left upper will turn on, indicating the function state has opened. Pressing the key again and this indicator will turn off, indicating the function state has shut off. Repeatedly pressing this key, the functions will turn on or off in turn. Upon the emergency switch stops, the motor will power off swiftly without affecting the electro thermal operation.

7. Manual Operation Keys

Keys	Usage	Operation Conditions
	Mold-opening operations	1. Mold is not reached to the termination position.
	Mold-closing operation	1.safe door input is normal 2.ejector retreat is in position 3.mold closing not reached final position 4.manipulator signal (mold closed) is connected (manipulatr use)
	Injection Operation	1.if use time-inject, inject time not reached 2.if use position, not reached inject final position 3.all sections of temp in charging barrel must within set range (no temp alarms) and cool boot for screw timing is up
	Suck back Operation	1.if E-ruler not being used, suck back time not reached 2.if E-ruler being used, not reached suck back termination position 3.all sections of temp in charging barrel must within set range (no temp alarms) and cool boot for screw timing is up
	Ejector advance operation	1. mold open reached termination position 2. core retreat limit is connected or its time is up (core use optional) 3. manipulator signal (ejector) is connected (manipulator use optional) 4. if E-ruler being used, ejector advance position not reached termination position 5. if E-ruler not being used, 1, stroke option is being used, not reached advance stop postion 2, time option is being used, timing for ejector advance not reached
	Ejector return operation	1. if E-ruler being used, ejector retreat position not reached termination position 2. if E-ruler not being used, 1, stroke option is being used, not reached retreat stop postion 2, time option is being used, timing for ejector retreat not reached
	Feeding Operation	1 Feed not reached termination position 2 all sections of temp in charging barrel must within set range (no temp alarms) and cool boot for screw timing is up
	Auto purging operation	1 Auto purging being used 2 times of auto purging not completed 3 all sections of temp in charging barrel must within set range (no temp alarms) and cool boot for screw timing is up

Keys	Usage	Operation Conditions
	multi-ejector operation	1.operation condition is same as ejector advance,ejector retreat 2 . set times of ejector not finished
	lubircating pump working	1.Totaltime of lubricatingnot completed
	male blowing operation	1. male blowing optional 2. male blowingtime not completed
	female blowing opeation	1. female blowing optional 2. female blowingtime not completed
	nozzle advance operation	1 .nozzle advance limit not being used, no condition 2. nozzle advacne limit being used, a not reached nozzle advance stop position b.timing for nozzle advance slow not reached
	nozzle retreat operation	1.no conditions
	mold adjustment option	1.when manual mode is being used for mold adjustment, press Down the key and then if indicator ligh flash means manual adjustment is allowed 2.when auto mode is being used for mold adjustment, press down the key twice and then if indicator ligh flash means auto adjustment is allowed
	mold adjustment backward operation	1. enter into manual adjustment mode 2. mold adjustment backward not reached its termination position
	mold adjustment forward operation	1 enter into manual adjustment mode 2 mold adjustment forward not reached its termination position

Keys	Usage	Operation Conditions
	core A advance operation	1 .Core A being used 2. core A advance not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core A retreat operation	1. core A being used 2. core A retreat not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core B advance operation	1 .Core B being used 2. core B advance not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core B retreat operation	1. core B being used 2. core B retreat not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core C advance operation	1 .Core C being used 2. core C advance not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core C retreat operation	1. core C being used 2. core C retreat not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core D advance operation	1 .Core D being used 2. core D advance not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	core D retreat operation	1. core D being used 2. core D retreat not reached termination position or time not completed 3. ejector retreat reached position or ejector retreat time is up
	line of Mk360 Keyboard Nitrogen recharge operation	1 stocker up limit not reached its termination position

Keys	Usage	Operation Conditions
	line of MK360 Keyboard nitrogen release operation	1.No condition;
	line of Mk360 Keyboard safe door open operation	1. Safe door open not reached its termination position or time not completed
	line of Mk360 Keyboard safe door close operation	1. Safe door close not reached its termination position
	line of Mk360 Keyboard Standby operation keys	
	line of Mk360 Keyboard Standby operation keys	

8. Setting Scope of Numeric Items


Number	Setting Items	Setting Scope	Unit
1	Time Setting	Digital ≤ 600.00	Second
2	Pressure Setting	Digital ≤ 160.0	Bar
3	Speed Setting	Digital ≤ 99.9	%
4	Back Pressure	Digital ≤ 160.0	Bar
5	Temperature Setting	Digital ≤ 999.9 (Measure) Digital ≤ 600.0 (set)	°C
6	Storage of Mold Data	Digital ≤ 999	Number
7	Predicted Turnout	Digital ≤ 999999999	PC

In case of the set values exceed the above-mentioned scopes, the system will not accept the numbers set and keep the original set values For the habit of data input, the data input of this system is display from right to left.

Chapter 3: Descriptions on setting parameters/functions

1. Main page of Starting up




Connect with power, turn the urgent stop switches, the operation light of the computer-RUN-flickers, the following menu shown on the display now the control system is running and it is ready to operate the machine.

2010-03-28						【*Manual*】		20:38:08	
Nozzle	1Segment	2Segment	3Segment	4Segment	5Segment	oil temperature	Mold number: 2512		
34.2	34.3	34.1	34.1	34.1	34.3	****	G-18CUP		
Setup: 50.00 s		Pressure: 20.0 bar		Cycle: 216.90 s					
Operate: 2.14 s		Flux: 20.0 %		back pressure: 0.0 bar					
<div>Temperature.OK</div> 									
Move mold: 593.9 mm			Ejector: **** mm		estimate production: 0 mode				
Screw: 6.15 mm			Screw speed: **** R/M		current production: 0 mode				
Machine Run Well									
Ready									



Press **MONITOR** key at any time after re-turning on the computer, and then enter the menu of the monitor menu of the machine. This menu is for monitoring temperature and machine running condition. The names and numbers of the moulds will be set in the mould information menu. The temperature scale and current oil temperature show the real value of each stage; thus its information cannot be modified. Each function of the menu is described as follows:

The descriptions on mode:

Mode	Meanings
	Motor is running
	Electric heating is operated
	Lubricant pump is working with oil

2.The descriptions on display:

Display	Meanings and descriptions
Manual	The running mode of the machine;
Injector	This section is heating;
Mold number	The current mold number;
Movable mold	Shows the current position of the mold. The unit: mm;
Screw	Shows the current position of the screw. The unit: mm;
Thimble	Shows the current position of the thimble. The unit: mm;
Pressure	The set pressure value of the current movement;
Flux	The set flux value of the current movement;
Estimated output	Estimated output of current mould number;
Output	Record the numbers of mould opening for current mould number during the automatic operation of the system;
Set	The time value and counter data of the current movement;
Operation	When a time value is set for current movement, only the operation time gradually reached set value, can next movement be proceeded, if number of times is set correspondingly the number of times would be displayed and to reached its set .
Cycle	Cycle time of actual operation of system;
Low temperature	Actual temperature is not within setting range, showing current ly all sections of temperature are abnormal
Screw speed	The number of rotation of the screw in one minute (unit: RPM);

3.Descriptions on alarm mode

Alarm	Source	Solution
short circuit of input terminal	1. There is no 24 v voltage output from power supply 2. Malfunction from main board 3. short circuit on peripheral circuit of input or output terminals	1. repair power supply 2. repair main board 3. check peripheral circuit to find out short circuit source
Neutron A is not reach set point Neutron B is not reach set point. Neutron C is not reach set point. Neutron D is not reach set point.	Neutron A,B,C,D was chosen by machine ,Limit connection of neutron A, B,C, D retreat must be done while at the time of eject-forward or multi-eject.	Check whether end switches of neutron A and B,C,D were connected correctly and can be press-fit normally. Please chose disable for neutron A and B,C,D while not using neutron functions

Alarm	Source	Solution
Rear safe door unclosed	Switches of X15 and X16 of rear safe door are in OFF status .	Please check whether switches of rear safe door correctly connect with ports X15 and X16
Please open safe door	In semi-auto operation, single cycle ends,but safe door is not opened	Please open safe door to take out made product, close safe door and then continue to work
Failure of sensor inspection	In automatic operation, when inspecting sensor is still not ON after thimble retreats of sensor cycle mode and mid-time is over, Failure of sensor inspection will be alarmed.	Eliminate faults of ejecting forward or ejecting backward and judge if electric eye was estopped. Key inspection should be on connections of sensor or sensor itself if light of X04 input port is on.
Mould opened is not reach set point	Clamping and open mould not completed within “ the time limitation of the mould opening or closing”	Reoperate mould opened or check mould position 1, if electronic ruler is 'able' state, check position reading 2, if electronic ruler is 'disable' state, check X12 to confirm it is connected
Mould opening/closing beyond fixed time	Mould opening/closing is not done within fixed time	Check if there are abnormalities in the process of mould opening/closing, if result is normal, adjust fixed time appropriately
Low- pressure protection time is up	Suppose low-pressure time is up, and yet not change to high-pressure, alarm will be on	Check if there are sundries in the mould, If result is no, adjust time of low- pressure protection appropriately
Fault of safe door	When only one of X00 and X01 is on, system alarms	Please check to see whether switches of Front /Rear safe door is connected correctly with input ports of X01 and X02
Feeding is not done within fixed time	While feeding, it is not done within fixed time	Check if there are any abnormalities during the process of feeding and check whether material inside charging barrel is none, if result is normal, adjust time of feeding appropriately
Failure of injection	Fail to press fit to stroke switch of injection inspection during the process of injection or fail to reach injection inspection point while choose electronic ruler	Check process of injection and adjust deviation value of injection inspection
Motor is malfunction	When there is signal inputs at motor protection point, system will be alarmed	Check if hydraulic motor was working with overload that cause thermal relay to have protection action
Cycle time is up	Automatic production cycle time exceeds set value	Check if there are abnormalities during the process of automatic production, if result is normal, adjust cycle time appropriately

Alarm	Source	Solution
Set output is reached	Machine stops when output of machine halt is started and the numbers of mould opening reached set value of output.	Solution: If you need the machine continues Running after the output reached, just set The [stop after alarm] in production menu as [out]; or reset the total mould opening of the current mould number .

4.Descriptions on operation/prompt mode

Alarm	Source
High temperature in 1,2,3, 4,5, sections Injection nozzle.	Current section real temp to machine hopper is higher than max temp value.. (Higher limit value of temp = setting value of temp + setting value of upper limit).
Low temperature in 1,2,3,4, 5, sections Injection nozzle.	Current section real temp to machine hopper is lower than min temp value.. Lower limit value of temp = setting value of temp - setting value of down limit).
Temperature short circuit in 1,2,3, 4,5, sections Injection nozzle	Current section temp line was shorted or faulted to machine hopper.
Auto material clearing completed	After setting Number of movements completed and when using auto material clearing
Auto mold adjusting completed	Auto mold adjusting completed when using mold auto adjusting.
Auto mold adjusting not completed	Auto mold adjusting not completed when using mold auto adjusting.
Enter manual mode first	Operate manual keys when under auto state..
Functions not selected	Certain function has not been selected when manual operate its keys.
Start motor please	When choose to use motor, pressed semi-auto/auto keys but motor yet not started.
Next cycle Prepared	In auto mode, the mid-time between completing a cycle and starting next cycle.
Sensor prepared	The mid-time has not been reached after withdrawing thimbles during auto sensor cycling.
Exit mould adjusting mode first	When operate non-[adjust forward, backward] keys under mold adjusting state.
Enter mould adjusting mode first	When operate [adjust forward, backward] keys under non-mold - adjusting state.

5. Setting for celerity information

快速設定



Press **CELERITY SET** key, enter the menu for fast setup 1 information, now as following:

2016.05.05【Fast setup 1】10:07:12

	Pressure	Flux	Place	Delay	Time	Eject Times
ejector advance fast	***	***	***	**	**	*
ejector advance slow	***	***	***	****	**	
ejector hold	***	***	***	***	***	
ejector retreat	***	***	***	**	***	
mold clamp slow	***	***	***	low pressure protection **** s		
mold clamp fast	***	***	***	mold clamping time limit **** s		
low pressure mold clamp	***	***	***	differential mold clamping *****		
high pressure mold clamp	***	***	***			
open mold slow	***	***	***	mold opening time limit ****		
open mold fast	***	***	***	Manipulator *****		
open mold intermediate speed	***	***	***			
open mold low speed	***	***	***			

Hint:set range:0.00~600.00

快速設定



Press **CELERITY SET** key twice, enter the menu for fast setup 2 information, now as following:

2016.05.05【Fast setup 2】10:07:12

	Pressure	Flux	Time	Place	Back pressure
Forward inject retreat	***	***	***	***	***
Feeding 1	***	***	***	***	***
Feeding 2	***	***	***	***	***
backward -inject-retreat	***	***	***	***	***
Inject 5 Segment	***	***	***	***	***
Inject 4 Segment	***	***	***	***	***
Inject 3 Segment	***	***	***	***	***
Inject 2 Segment	***	***	***	***	***
Inject 1 Segment	***	***	***	***	***
pressure holding 4	***	***	***	Cool time **** (s)	
pressure holding 3	***	***	***	Feed limit **** (s)	
pressure holding 2	***	***	***	Total time **** s	
pressure holding 1	***	***	***	Inject way *****	

Hint:0.time 1.place


Fast setup 1 and 2 menus are parameters cluster menus common used by jet plastic machines. These two menus can provide important parameters needed daily adjustment by machines, including: mold close, mold open, injection, hold pressure, plasticization, ejector forward .

6. Set moId close information



Press key, enter the menu for setting mold close information, now the menu is as following:

2016.05.28【Mold close】10:07:12

593.9 mm


system pressure: ...
system flux: ...
Mold close pressure: *****Bar

	slow speed	fast speed	low pressure	high pressure
Pressure (bar)
Flux(%)
Place(mm)

low pressure protect(s) ...
Mold close limit(s) ...
Differential mold close

Hint:
Machine Run Wellmold close slow

Descriptions on setting parameters/process/function mold



- (1). Process: while closing mould, enterslow clamping first, and thenenter fast clamping stroke Arrives at[508.8], and then enter low pressure clamping when stroke runs another [109.0].And then enter high pressure clamping when stroke runs another [2.0] till clamping completed.It alarms [low pressure mould protection time is over] when the low pressure time is over but not enter the high pressure yet.
- (2). Low pressure protection: Set a smaller low-pressure time for mould closing, it is better to be fitting, otherwise,the mould can not be protected.
- (3). Limitation to mould closing: time limitation to mold closing,please set it longer, and it is Better to be fitting, otherwise, the system alarms [mold open/close not completed on time].
- (4).Differential mould closing: press enter key to select[on]of[off], output when select [on]for quick mould closing and Y12 iswith signal, when select[off] for quick mould closing,and Y12 is without signal.

7. Set moId open information

開鎖模


M.PLT

Press key twice, enter the setting mold open information, the menu is as following:

2016.05.28

【 Mold open 】

10:07:12

593.9 mm

system pressure: ...
system flux: ...
Mold close pressure: ****Bar

..... (bar)
..... (.)
..... (mm)

slow speed	middle speed	Fast speed	slow speed
...
...
...


Mold open limit(s) ...
mechanic hand ☒

Hint:0.disabled 1.enabled

Machine Run Well

mold close slow

Descriptions on setting parameters/process/function mold



- (1).Process: while opening mould, enter slow mould opening first, and then switches to fast mould Opening when stroke arrives at 50.5mm, and then switches to middle speed mould opening when arrives at 215.5mm, and then switches to low speed mould opening when arrives at 550.8mm,and then mould opening completed when arrives at 600mm
- (2). Mould open limit: time limitation to mould opening and clamping, please set it longer, and it is better to be fitting, otherwise, the system alarms [mold opening/clamping not completed on time].
- (3).The function of mechanical arm : ifa mechanical arm is needed, please select [on] for it. After [on] selected,the machine will output manipulator signal while mold opening completed. Before mold close,the Next cycle starts only after receiving the manipulator signal, and stop the output of it at the same time.

8. Set the injector information




Press **INJECTION** key, enter the menu for setting injector information, now the menu is as following:

2016.05.28

[Injection setup]

10:07:12



system pressure: ...

system flux: ...

Injector pressure:***** bar

	5Segment	4Segment	3Segment	2Segment	1Segment
Pressure (bar)
Flux(%)
Place (mm)00
Time (s)

Injection total time

... (s)

Injection method


...

Hint:0.place 1.time

Machine Run Well

mold close slow

Descriptions on setting parameters/ process/function mold



- (1).Process: while injecting, 1stage injects plastic first, and then switches to stage2whenarrives at 220.0mm, and then switches to stage 3 when arrives at 150.9mm, and then switches to Stage 4 when arrives at 98.5mm, and then switch to pressure retaining when arrives at 10.0mm
- (2).Injection total time; monitor normal travel of injection.It starts to count when entering into injection and wait to be time up,if choose [injection total time],it will switch to pressure holding Regardless of distance reached or not,. Thus the injecting time should be set longer than real time.
- (3).Injectoion pattern: when screw electronic ruler is on ,[Position] or [Time] can be selected.a. If Select [position], injection will be switched to pressure maintaining from electronic Ruler position; b. If select [time],injection will be switched to pressure maintaining from Time.

9. Set the hold pressure information


射出

Press **INJECTION** key twice, enter the hold pressure information, the menu is as following:

2016.05.28

【Hold pressure】

10:07:12



6.15 mm

system pressure: ...

system flux: ...

Injector pressure:***** bar

	4Level	3Level	2Level	1Level
Pressure (bar)
Flux (%)
Time (s)	1.00	1.10	2.59	1.25
Slope

Injection check:

allowable deviation: ... mm

collect mold number: ** mode


reference standard: ... mm

Hint: set range:20~100


Machine Run Well

mold close slow

Descriptions on setting parameters/ process/function mold



Time 1.00 1.10 2.59 1.25




(Curve graph of slope function)

- (1). Process: when entering into phase of pressure maintaining after injection, firstly from level 1 pressure of pressure maintaining and speed movement when [level 1 time is up] enter into level 2 pressure maintaining And then enter into level 3 of pressure maintaining when [level 2 time is up],and enter into level 4 of pressure maintaining when [level 3 time is up] and then switch to storing delay when [level 4 time is up].
- (2).Method of application: when level 1 pressure maintaining control is enough for condition of moulding control method is as below:please input time for level 1 pressure maintaining on level 1 time column, level 2 pressure maintaining time [0.00 set to be 0 while disable],level 3 pressure maintaining time [0.00 set to be 0 while disable],level 4 pressure maintaining time [0.00 set to be 0 while disable]
- (3). Slope function: Controlling pressure maintaining means to hold pressure or slope change, referring to page to setting, the actual pressure output is as above chart.
- (4). Injection inspection:[Disable] and [Enable] can be selected. Computer will automatically take average of injection terminal of first 1-100 output as inspection point, user can set allowable error of numerical value on page of pressure maintained. If exceeds set mould numbers, and result is not reached or exceeded inspection range,[Injection fail] will be alarmed and meantime it will be regarded as defected product by output management .


10. The feed/suck back/cooling setup information

儲料
FEEDING

Press key , enter the feed/suck back/cooling setup information ,now the menu is as following:



Descriptions on setting parameters/ process/function mold




- (1). Process:After phase of pressure maintaining, it will switch to storing 1 when injection retreats move To20.00mm, and then switch to storing 2 when move to150.0mm,and then switch to suck back backward when move to 220.00 and finish storing when move to 250.00mm.
- (2).Feed limit Time : Monitor time for no material. It is regarded as no material when time is up but Feeding is not completed, therefore, settime limit longer than actual feeding time, otherwise, [feeding not completed on time] will be alarmed.
- (3).Cooling time: In auto mode, injection and pressure maintaining are completed, cooling time starts To count, time for feeding and injection retreats is also part of cooling time. If movement time exceeds cooling time, cooling time will end, and mould opened can be proceeded only if feeding,in jection retreats finished, conversely, cooling time ends to open mould immediately.
- (4)Feeding time delay: Set delay time when under auto state and then to proceed for feeding.

11. Set the auto clear setup information


儲料

FEEDING

Press key twice, enter the auto clear setup information , now the menu is as following:



Descriptions on setting parameters/ process/function mold



- (1).Process: How to use the stuff auto-clearing up function. In manual mode, press key of material Auto-clearing up, the system starts the material auto-clearing up process, first is process of with drawing, and then cycles automatically according with process shown in the diagram above.
- (2) Automatic material clearing: Under manual mode, press [automatic material clearing] key, for automatic material clearing movement
- (3)Times of material clearing: Repeat movement of feeding and injection..
- (4) Material restoring time: Under auto mode, to proceed feeding movement when move forward completed and time is up then change to injection movement. .

12. Set the nozzle information

座臺/調模

Press **NOZZ/ADJ.** key, enter the menu for setting nozzle information, now the menu is as following:

2016.05.28 【Nozzle setup】 10:07:12

6.15 mm

system pressure: ...

system flux: ...

system back pressure: ...

	Nozzle advance slow	Nozzle advance fast	Nozzle return
Pressure (bar)
Flux (%)
Place (mm)
Time(s)

Auto nozzle return position

Nozzle return end method

Hint: 0.time 1.location

Machine Run Well mold close slow


Descriptions on setting parameters/ process/function mold

- (1) Move forward slow motion: ① When electronic ruler is [disable], move forward encounters switch of move forward [X06] and then change to move forward slow and mould combination and time will counts to end of move forward ② when electronic ruler is [Enable], move forward Fast or slow was controlled by position of electronic ruler. (Function: To prevent crashing and protect mould)
- (2) Position of auto base retreats: [Disable] or [Feeding completed] or [cooling completed] can be selected, when [Feeding completed] is selected and under auto mode, move backward will be proceeded after feeding and sucking back finished, and when [cooling completed] is selected and under auto mode, move backward will be proceeded after cooling is finished.
- (3) Move backward termination methods: ① When electronic ruler is [Disable], [travel] or [time] can be selected, when [travel] was selected, the position of automatic base was controlled by base stopped backward limit switch [X07], and when [time] was selected, the retreat of automatic Base was controlled by time. ② when electronic ruler is [Enable], [position] or [time] can be selected, while [position] was selected, the retreat of automatic base was controlled by position Of electronic ruler; while [time] is selected, the retreat of automatic base was controlled by time. (Notice: Under manual mode, press [nozzle Ret] key and nozzle ret movement will not be affected.)

13. Set the mold adjusting information

座臺/調模

Press **NOZZ/ADJ.** key twice, enter the menu for setting mold adjusting, now the menu is as following:



Descriptions on setting parameters/process/function mold

- (1).adjust way: [Manual] or[Auto] can be selected,the pressure for mouldadjusting is about 20 - 50 bar, the speed is 30-60%.
- (2).fine adjust teeth number: [Time]or [gear number]can be selected. Select [time] if the machine is not mounted with sensor; the initial value is controlled by [time]; select [gear number] if there is a sensor, the initial value is controlled by [gear number].
- (3).The time of mold closing: In auto mould adjusting, time limitation for mould closing.
- (4).How to use auto mold adjusting: Select[auto]for mold adjusting, press the key[mold adjusting] and [auto mould adjusting], and than enter the mode of auto mould adjusting as soon As the exit shut. The movement pressure and flux of adjusting forward and backward in the process of auto mould adjusting is controlled by a set value in the fine adjusting box. The sound of can be heard and [mould adjusting completed] shown after the mould adjusting completed.
- (5).Initial adjustment number of teeth: the no. of teeth which is nothing change in number of teeth after 1st mold thin of auto mold adjustment and then open mold and readjust.

14. Set the ejector forward information


托模/中子

Press **EJE/CORE** key , enter the menu for setting ejector forward,now the menu is as following:

2016.05.28

【Ejector setup】

10:07:12



200.0 mm

system pressure: ...

system flux: ...

system back pressure: ...

	Ejector return	Ejector advance fast	Ejector advance slow	Keep
Pressure (bar)
Flux (%)
Place (mm)	*****	*****	*****	*****
Delay(s)
Time (s)

Ejector times

Ejector Method

stop holding

Hint:0.times 1.vibrating 2.retaining

Machine Run Well

mold close slow

Descriptions on setting parameters/ process/function mold

- (1) Times fixed : [Ejecting forward] → [Ejecting forward stopped] -[Maintain] -[Ejecting backward] [Ejecting backward stopped] as one cycle, move in according to times.
- (2) Vibrating:[Ejecting forward stop] -[Ejecting forward stop]-[0.1Ejecting backward]-[time is up] as one cycle, set movement according with ejecting times, and ejecting backward movement will stop when times is finished.
- (3) Remain:[Ejecting forward]-[Ejecting forward stop] movements stop ,ejecting backward will only Be conducted only before mould closing of next cycle.(Notice:[Remain] movement will not be limited by times, movement will be only conducted once when [times of ejecting] is larger than
- (4). Backward delaying: after ejecting forward completed, the ejecting backward movement occurs while the set time delayed.
- (5). Forward delaying: after mould opening completed, the ejecting forward movement occurs while the set time delayed.
- (6) Maintaining function: If maintaining time set to be 0,there is not maintaining function.The Retaining function is for retaining pressure,speed and starting retaining time for the output after ejecting forward completed. The retaining movement is completed as soon as the time is over.
- (7). Retain maintaining function: [Enable] and [Disable] are available. Select the ejecting mode as retain while under semi-auto state. When retain maintaining selected disable, the process:ejecting forward stop--maintaining(time is up or opening and closing safe door)--cycle over,conversely, ejecting forward stop--cycle over.
- (8) [Notice]:a.While ejecting is under manual mode, it will not be limited by times.(But while multi-ejecting is under manual mode, it will be limited by times)b. Ejecting function will be disable when [ejecting times] was set to be 0.

15. Set core A B information


托模/中子

Press **EJE/CORE** key twice, enter the menu for setting coreA B information, now the menu is as following:


2016.05.28


【Core A B setup】


10:07:12



Movement mold
593.9 mm

system pressure: ... 

system flux: ... 

system back pressure: .. 

	Core Ain	Core Aout	Core B in	Core Bout
Pressure (bar)
Flux (%)
Time(s)	3.0	3.0
Count(s)
Start stroke	Mold close stop	Mold open stop	front mold close	front mode open
Start position

Core A

Disable

A method

Way

Core B

Disable

B method

Time

Hint:0.time 1.way 2.count

please turn on the oil pump.

Descriptions on setting parameters/ process/function mold

- (1) Core A function: [Neutron],[Twist],[Disable] can be selected, while selecting neutron, inlet valve of core A will output meantime when injecting, while selecting twist, inlet valve of core A will not output meantime when injecting.
- (2)Core B function:[Neutron],[Twist],[Disable] can be selected, while selecting neutron, inlet valve of core B will output meantime when injecting, while selecting twist, inlet valve of core B will not output meantime when injecting.
- (3)Mode A. [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the movement of loose core A terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X25, X26] of input point shows ON; if [count] selected, pipe Thread control can be taken, and the movement termination is decided by the number of pipe tread pulse inputted through [X25].
- (4). Mode B: [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the terminate until the stopsignal [X30, X31] of input point shows ON; if [count] selected, pipe movement of loose core B terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X30, X31] of input point shows ON; if [count] selected, pipe tread control can be taken, and the movement termination is decided by the number of pipe tread pulse inputted through [X30]
- (5). Time: When neutron A or B select time, forward/backward of neutron was controlled by time. Gear number: When neutron A or B select gear number, forward/backward of neutron was controlled by gear number..
- (6). Start stroke: the neutron start the position of movement (neutron in: [before lock the mode], [before the low pressure], [before the high pressure] and [the lock mode stops]; neutron out: [Before the mode opening] [before the middle speed], [before the low speed] and [the mode Opening stops]), that is, where the template is moving, setup the action of neutron A and B.
- (7).Start position: The position for starting the movement of core knock in or knock out where the mould stops-- is a set value for the movement of core loose A and B.

16. Set core C D information




Press EJE/CORE key three times, enter the menu for setting coreC D, now the menu is as following:

2016.05.28

【Core C D setup】

10:07:12



Movement mold
593.9 mm

system pressure: ...

system flux: ...

system back pressure: ..

	Core A in	Core A out	Core B in	Core B out
Pressure (bar)
Flux (%)
Time (s)	3.0	3.0
Count (s)
Start the way	front mold close	Mold close stop	Front high pressure	Front mode open
Start the place

Core A

Disable

A method

Way

Core B

Disable

B method

Time

Hint:0.time 1.way 2.count

Machine Run Well

mold close slow


Descriptions on setting parameters/ process/function mold

- (1) Core C function: [Neutron],[Twist],[Disable] can be selected, while selecting neutron,inlet valve of core A will output meantime when injecting, while selecting twist, inlet valve of core C will not output meantime when injecting.
- (2)Core D function:[Neutron],[Twist],[Disable] can be selected, while selecting neutron, inlet Valve of core B will output meantime when injecting, while selecting twist, inlet valve of core D will not output meantime when injecting.
- (3)Mode C. [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the movement of loose core A terminated; if [stroke] selected, the movement of loose core will not terminate until the stop signal [X25, X26] of input point shows ON; if [count] selected, pipe Thread control can be taken, and themovement termination is decided by the number of pipe tread pulse inputted through [X25].
- (4). Mode D: [Time], [stroke] and [count] can be selected. If [time] selected, set the time till the terminate until the stopsignal [X30, X31] ofinput point shows ON;if [count] selected, pipet movement of loose core B terminated; if [stroke] selected, the movement of loose core will not Hread control can be taken, and the movement termination is decided by the number of pipe tread pulsein putted through [X30]
- (5). Time: When neutron C or Dselect time, foward/backward of neutron wascontrolled by time. Gear number: When neutron C or Dselect gear number,forward/backward of neutron was continue rolled by gear number..
- (6). Start stroke: the neutronstart the position ofmovement (neutron in: [beforelock the mode], [before the low pressure], [before the high pressure] and [the lock mode stops]; neutron out: [Before the mode opening] [before the middle speed], [before the low speed] and [the mode Opening stops]), that is, where the template is moving, setup the action of neutron Aand B.
- (7).Start position: The position for starting the movement of core knock in or knock outwhere the mould stops-- is a set value for the movement of core loose C and D.

17. Set blowing information


托模/中子
EJE/CORE

Press key fourth, enter themenu for setting airblow information, now themenu is as following:



Descriptions on setting parameters/ process/function mold

- (1).Why blowing air: This function can be used in the stamping mold that need air blow.
- (2).Time delay: Delay first when arrives automatically atthe position of airblow, andthan blow air when delay timestarts.
- (3).Start the way: you can select[before the mold opening] or[after the mold opening] to settthe value of blowing.
- (4).Starting position: [Pre-mold opening] can be selected. [Pre-mdd opening] is taken as a set value for the movement of air blow.
- (5).Function mode: [On] or [Off] can be selected,no movement of air blow if [Off] is selected.



18. Set time/count information

時間

TIME

Press key, enter the menu for setting time/count information, now the menu is as following:

2016.05.28
【Time/count setup】
10:07:12

lubricate mold number <input type="text" value="."/>	cycle waiting time <input type="text" value="..."/>
lubricate total time <input type="text" value="..."/>	sensor detection time limit <input type="text" value="..."/>
lubricate time <input type="text" value="..."/>	Manual movement time limit <input type="text" value="..."/>
lubricate intermittent <input type="text" value="..."/>	fault alarm time <input type="text" value="..."/>
The blowing key <input type="text" value="Key"/>	cycle time <input style="background-color: red;" type="text" value="..."/>

System boot time h m


Auto runs time h m

Motor runs time h m

Hint:range:
emergency stop notreleased

Descriptions on setting parameters/ process/function mold


- (1). Lubricate mold number:Count mold opening times.The oil pumpstarts when mold opening times reach the setvalue.
- (2). Lubrication Total time : the total time spent in this lubrication.
- (3). Lubrication time: the output of the repeated operation with the total time for lubricatin.
- (4). lubricate intermittent:The interval of the repeated operation with the total time for lubricatin.
- (5). Cycle Wait time: During auto process, it is the time between completed thimble movement and starting a movement of moulds clamping of next cycle.
- (6).Cycle time: The time limitation to operation cycle in automatic process. The system alarms [cycle time is over] when the real operating time is longer than cycle time limitation.
- (7).Movement time limitation:the max time permitted when output movement.
- (8).Error alarm bell: The max time when error output occurs. To avoid long time alarming, the bell stops alarm when time is over.
- (9) Alarm interval: The time between alarm output and stop in alarm time.
- (10).Lubrication process: As it shows in the follow chart ,During the output time of lubrication, if it fails to detect any lubrication pressure signal, it would trigger an alarm, telling that the lubrication is failing. If “opping working” after the failing of lubrication is chosen, then it would stop lubricating and would change to work in manual mode and stop the engine after the cycle of the alarming.



19. Set temperature information



Press **TEMP.** key, enter the menu for setting temperature information, now the menu is as following:



Descriptions on setting parameters/ process/function mold

The set temperature value is 0.1℃(Celsius). The temperature of the hopper of injection molding machine is close-loop controlled after it is fed back to controlling system by K style thermal electriccouple.

The system provides total 6 stages of temperature control and 1 stage oil temperature testing. [Open-loop] /[close-loop]can be selected to control temperature for injection nozzle. The system monitors The temperature in every area to find out if the temperature ove passes the set top and bottom limitation. It cannot inject or melt plastic if the temperature is lower than the bottom limitation and than the cold preventing screw starts. It alarms when the temperature is higher than the top limitation. The temperature of each stage is shown on the main menu.

Half of temperature functions: select use, at this time, the temperature setup value is half of the current showed setup value.

Cold boot: After the boot, the actual temperature in each area will be within the setup scope.

References on some plastic densities andpipe heating temperatures					
Material abbreviation	Density	Heating temperature	Material abbreviation	Density	Heating temperature
A. B. S	1. 01-1. 05	190-270	PMMA	1. 17-1. 20	180-260
PS	1. 05	190-240	PPO	1. 08-1. 09	260-330
A. S	1. 06-1. 07	180-250	PA/NYLON	1. 08-1. 17	230-290
H. P. S	1. 05-1. 08	220-280	NYLON66	1. 03-1. 15	280-330
L. P. S	0. 91-0. 93	150-260	PVC/S	1. 20-1. 40	150-180
H. P. E	0. 94-0. 96	190-260	PVC/H	1. 30-1. 58	160-200
P. P	0. 98-0. 90	200-290	P. E. T	1. 38-1. 41	280-310
P. C	1. 2-1. 22	280-320	P. T	1. 41-1. 52	220-280
P. O. M	1. 41-1. 42	190-230			

20. Hot runner temp setup information

温度
TEMP. key twice, enter enter into the page of hot runner temp setup, and page will be as follow:

>>temperature test 【Hot runner temp setup】 10:07:12

hot runner heating electric heat status

	Ek0	Ek1	Ek2	Ek3	Ek4	Ek5	Ek6	Ek7	Ek8	Ek9	Ek10	Ek11
Actual	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****
Display	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****
Setup	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****
max limit	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****
mini limit	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****	*****

Hint:range:0.00~99.99

Machine Run Well mold close slow

Descriptions on setting parameters/process/function mold

Attention: the mold temp control function provides 12-section temp heating

21. Set warm-up information



Press **TEMP.** key three times, enter the menu for setting warm-up information, now the menu is as following:

2016-05-18 【Warm-up setup】 16:40:30

Pre-heat function

Week	Monday	Tuesday	Wednesday	Thursday	Friday	Saturday	Sunday
boot starts setup	ON	OFF	OFF	OFF	OFF	OFF	OFF
boot time
power off setup	ON	OFF	OFF	OFF	OFF	OFF	OFF
power off time

Hint:machine runs well

Description on setting parameters


Warm-up function: Can set a time for seven days a week in advance. The system controls the heating system to heat through the set value of the intraday [on]/[off] time. The system heats automatically the hopper to working temperature before operator comes to the office. The operator's waiting time for heating hopper is decreased.

*[note]: The input value of time adopts the input value of 24 hours system. 00:00 is 12: 00 Midnight.

22. Set mold data information

資料

Press **DATUM** key, enter the menu for setting mold data information, now the menu is as following:



Mold number	mold name	saving date
0	A Cup	2016-6-10 14:38:52
1	B Cup	2016-6-07 13:39:52
2	C link	2016-6-06 13:30:52

Descriptions on setting parameters/process/function mold

- (1).Mold number: this system can store 10 mould numbers. The system can provide automatically the information of the modified mold number after they have been modified.
- (2).How to store mold: Move cursor to the box of mold numbers, key in the mold number; and than move the cursor to the box ofthe name of the mold, key inthe name of the mold; this system provides the input mold with English/Chinese phonetic alphabet; move the cursor tobox of storage after the name has been keyd in and than press [enter] to store the name.
- (3).How to get mold: Move cursor tothe box of moldnumbers, key in the mold numberthat will be read out, move thecursor to the boxof reading out, press[enter]to read out. Thefunctions of getting mold is limited within manual mold to prevent accident occurs; in the semi-auto/auto mold, the accident is caused by the influence of bad products, which comes from the sudden varying of the set parameters in the menu.
- (4).How to delete: Move cursor to box of mold number, key in the mold number that will be deleted, and than movethe cursor the box of deleting, pressthe [enter] to delete. The current mold number can notbe deleted.
- (5).View method: a: move cursor to theup and downbutton to view, b, [initial sequence no display]: to locate by initial sequence no.and then use the up and down key to view.
- (6)Mold no.1 as standard mold parameter and this is system self-own so no need to be stored, and when need to be stored change mold number

23. Amendment history information

資料

Press **DATUM** key twice, enter the menu for amend history information, now the menu is as following:


2016-04-17		【 amendment history】			14:30:52	
record times		3	display initial sequence no		3	up page
						down page
						delete
No	uder ID	amend time	amend picture	amend project	original value	amend value
		14:38:52	Mold close	middle speed	0.00	9.00
		13:38:52	Hold pressure	low pressure	0.00	30.00
		12:38:52	Mold open	3Level Pressure	0.00	20.00

Descriptions on setting parameters/process/function mold


- (1).Page number: This screen can keep at most 999 items of records,
- (2).View method: a: move cursor to the up and down button to view, b, [initial sequence no display] : to locate by initial sequence no.and then use the up and down key to view.

24. Set special parameters information

Press **1**_{STU} key , enter the menu for setting special parameters, now the menu is as following:



- (1) Mid / big pump start: when the setup executive action flow value is bigger than the setup mid/ big pump flow output value, the mid/big pump output point will have output.
- (2) Move the cursor to select the [special parameters>>] button, press the input button, a new page will pop up. At this time, the screen displays as follows:



- (2a) Adjustment of LCD contrast: move the cursor to this place, input the data [adjustment range "1-100%"]. Under appropriate brightness, the higher the contrast is, the richer the color will be (Note: when LCD is the STN screen, it can be valid).

- (2b) LCD brightness adjustment: move the cursor to this place, input the data [adjustment range "1-100%"], the screen will display the darkness & brightness degree according to the data entered.
- (2c) LCD color setup: the system can provide [normal/anti-color] two options, move your cursor to this place, press [input] button to select LCD color display.
- (2d) LCD backlight time: the system has the function of screen protection, the background light time is adjustable, the setup scope is 1~6 minutes. If the keyboard is not pressed in the setup time, the background light will be automatically turned OFF. (Note: if any button is pressed, background light will be on)
- (2e) Function of key sound: Select [use], you will hear a "tick" sound when the key is pressed, if do not select, no sound.
- (2f) Key sound scope: move your cursor to this place, input the data [scope "0-10"] to adjust voice volume.
- (2g) Correction of Touchscreen: click on the [Correction] button to enter the correction page (Note: only if keyboard has the touch function, the correction can be valid)
- (2h) Network connection status: the network connection status is indicated with colors.
- (2i) Current IP: show the IP address of the machine.
- (2j) Current connection state: show the network connection status: disconnect / connect.
- (3) Move the cursor to select [language conversion>>] button, press the input button, a new page will pop up. The screen displays as follows:



- (4a) Language options: the system provides [Chinese / English / Russian / Japanese] the four language options, move the cursor to this place, press the [input] button, you can carry out the conversion. (Note: the language categories of the system can be set up by users)

25. Set Ethernet information

Move the cursor to select [Ethernet] button, press the enter button to eject anew page, which will display the following information:

Ethernet/ CAN-Bus Configuration		Return
<div> <div> <h3>Ethernet Setup</h3> <p>Ethernet <input type="text" value="Use"/></p> <p>Remote Update OPWIN <input type="text" value="Allow"/></p> <p>IP <input type="text" value="192.168.0.250"/></p> <p>Mask <input type="text" value="255.255.255.0"/></p> <p>Gateway <input type="text" value="192.168.0.1"/></p> <p>MAC <input type="text" value="FF:FF:FF:FF:FF:FF"/></p> <p><input type="button" value="Revise"/></p> </div> <div> <h3>CAN Setup</h3> <p>Own ID 1 <input type="text" value="500"/> Acceptance ID 1 <input type="text" value="600"/></p> <p>Own ID 2 <input type="text" value="0"/> Acceptance ID 2 <input type="text" value="0"/></p> <p>Own ID 3 <input type="text" value="0"/> Acceptance ID 3 <input type="text" value="0"/></p> <p>Own ID 4 <input type="text" value="0"/> Acceptance ID 4 <input type="text" value="0"/></p> <p>Own ID 5 <input type="text" value="0"/> Acceptance ID 5 <input type="text" value="0"/></p> <p><input type="button" value="Revise"/></p> </div> </div>		


Parameter Setup Instructions

- (1) Ethernet: With the remote communication function, the user can prepare programs and change different versions of software remotely. The network connection software provided by us allows the network connection and management of 255 injection molding for production machines by one PC host and the production of each machine can be calculated accurately and production data can be printed and managed conveniently.
- (2) Remote OPWIN Update: The update item can brespectively set as [Allow/Forbid], choose [Allow] to prepare programs remotely and change different versions of software and conduct system program updates.
- (3) CAN_bus: Such setup can realize the function of one keyboard connecting with multiple hosts.

Note:

- a. The above revised parameters will not come into effect unless the cursor moves to [Revise] for confirmation and a restart is made.

Method for ethernet PLUG switch to aviation plug



- (4) User management data setup: move cursor to press **【user management】** button and then the page will be as below:

User manage							« Return				
» Add		» Modify		» Delete		» Login		Record NO	1	Current user	No user login in
Page NO		OFF		Muit-use		Login		Boot login		OFF	
SN	User ID	Card ID	User name	Level	Save date	Modify date					

- (4a) Multi-user function: There are **【close】** **【open】** available, use password to log in when select to close, and use magcard when select to open.
 (4b) Listing: Show all users information: User ID
 (4c) Add modification delete three functions available
 (4d) Click add and then the following chart will be popup

Add new user				Return	
loading type		<input type="radio"/> Password <input type="radio"/> Magcard <input checked="" type="radio"/> Password+Magcard			
user name		Spell type-in			
Authority level		Operator			
new account no		*****		» magcard card registration	
input password		*****		new magcard ID	
password confirm		*****		Confirm(Y)	
Confirm(Y)		Confirm(Y)			
Hint...loading...		Hint...loading...			
operation over					

- a、Loading type: There are **【password】** **【magcard】** **【password or cagcard】** available, use password to log in **【password】** mode; and use cagcard to log in in **【cagcard】** mode, and use password or cagcard in **【password or cagcard】** mode.
 b、User name: shows user information
 c、Authority level: There are **【operator】** **【management】** **【technician】** **【dept manager】** **【technical engineer】** or **【system management】** options available which isto meet different category peoples demand ofmanagement.

- d、 new account no: means the accountno for login
 - e、 input password : means the passwordno for login
 - f、 Password confirmation : input the passwordagain to confirm its accuracy
 - g、 New account noconfirmation : after done datainput press thisbutton to be listed .
 - h、 Magcard card registration : use magcard to punch NFC (within 2cms) and hold 2seconds , punch again whenheard the sound of Di andsee the hint : punch again , please .
Then remove the card beyond 10cms over NFC and then move back punch again , the data collection is finished when heard the sound of Di, finally move cursor to confirmation to press it.
- (4e) Press Enter button when password.

Modification user		Return
loading type	<input type="radio"/> Password <input type="radio"/> Magcard <input checked="" type="radio"/> Password+Magcard	
user name		Spell type-in
authority level	Operator	
new account no	****	>> magcard card registration new magcard ID <input type="text"/>
input password	****	
password confirm	****	
	Confirm(Y)	
		Confirm(Y)
Hint...loading...		Hint...loading...
operation over		

- a、 User serial number : input the serial number which need to revise , all user data can be changed based on their actual need , and for how to input data please refer to Way of adding new user.
- (4f) Click delete and then the following chart will be as below..

Delete User		Return
single operation	lot operation	
user sequence no	1234	user sequence no <input type="text"/> 0 <input type="text"/> 0
user name		
	Confirm(Y)	Confirm(Y)
Hint...loading...		Hint...loading...

- a、User deletion : single operation. ; continuous users will be deleted in bulk operation mode (prudent operation)

5.user list

User manage« Return

Page NO

OFF

Muit-use

Login



Boot login

OFF

SN	User name	Level	Enter date/time	Log-on date/time	Running time	Output count

- a、Use to record all user data, user name, authority level, loading date, cancellation date, run time and production during period.

26. MES---setup of injection molding workshop management system (optional)

Press  key four-time (MK310, MK320 and MK330) or press  key (MK360) and then MES--function page will be showed as below:

2016-05-17 【MES functions selection】 14:30:52

Selection of production type
Selection of Production order Number
Production finished
Selection of machine halt types
Quality management
Sub-order

MES function ☐ Enable

After selecting MES function, please select [Production type] and next select [Production Order No.] before enter into automatic production, otherwise unable to enter into [Automatic Mode]

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

2016-04-17 【MES Production type selection】 14:30:52

production type execute or not Current production types

Number	Type
1	Production by orders
2	Production over machine adjustment
3	Production without orders
4	Production at abnormal status
5	
6	
7	
8	
9	

Production type, Production Order No. are to proceed at manual mode.

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

Description on setting parameters

- (1) MES function selection: [Enable], [Disable] option, machine is in MES management mode while select [Enable], conversely, it is in Standard mode.
- (2) Production type selection: [Production by orders] [Production over machine adjustment] [Production without orders] [Production at abnormal status]. Operational method: Please input production types of sequence no. in [Production types selection] based on actual situation, next select [YES] on [Execute Or not], after successful execution, chosen sequence will be displayed on [Current production type].
Notice: MES function is only available for keyboard with Ethernet function.

2016-05-17 【 MES Production Order No selection】 14:30:52

Production Order No execute or not Current production Order No

Number	Shift	Order No	production No	Mould No		
	Status	Start time	Finish time	Pre-Production Q	Produced q	Defected q
1	Day shift	PD-201305154-0001	QS196-CCF	1968-8-6		
	No P.			7000	0	0
2	Night shift					
	No P.					
3						
	No P.					
4						
	No P.					
5						
	No P.					

Hint:

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

2016-05-17 【 MES Production finished】 14:30:52

current production type advanced warning function

current production no advanced warning mould

Pre-production quantity is reached, continue or stop Warning time

continue to produce

Pre-production quantity is reached, continue or stop

Pre-Production mould NO(mould)	MES Pre-Production quantity NO(number)	Defected quantity NO(number)
2100	0	0

MES Pre-Production quantity NO(number)

Output number(mould)	One mould (number)	Produced quantity (number)
2100	5	0

This page is only valid when production is reached set qty and?production by order

Hint:

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

Description on setting parameters

- (1)、Selection of Production order No.: The choose of Production order No. Can not be empty when [Selection Of production types] is [Production by orders].Please choose the order NO. That need to be produced according to actual production situations ,and the operation method please refer to [Selection of production types.]
- (2)、Production termination:When [Selection of production types] is [production by orders]and[output was reached set pont] ,the following page will be automatically jump out while alarming such as: [finish this order] or [continue to production] and [continue same production output] ,choose one of the two.Please choose[termination]when the set output of this order is being reached,and if want continue to production then the needed produced output must be input first and next choose [continue to production].

2016-05-17 【MES machine halt types selection】 14:30:52

machine halt types execute or not Current machine halt types

Number	Status of machine halt	Number	Status of machine halt
1	Arlam	11	
2	change mould	12	
3	change order	13	
4	change material	14	
5	adjust machine	15	
6	Maintenance	16	
7	Plan	17	
8	Repair	18	
9		19	
10		20	

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

2016-05-17 【MES Quality management selection】 14:30:52

Complement No. of order execute or not Complement No. of order

NO	Defected reasons	NO	Defected Qty	NO	Shift	Order No
					Pre-set produced quantity	inferior product
1		11		1		
2		12		2		
3		13		3		
4		14		4		
5		15		5		
6		16				
7		17				
8		18				
9		19				
10		20				

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

2016-05-17 【Sub-order】 14:30:52

NO	1	2
Sub-order no	0	0
production status	to be in production	to be in production
pre-production sub-order qty	0	0
completed sub-order qty	0	0
total finished mold	0	0
next sub-order pre-production qty	0	0

production types Production Order No Production finished machine halt types Quality management Sub-order Monitor

Description on setting parameters

- (1) Selection of machine halt types: Please select reasons of machine halt by jumping out of this page when changing automatic mode to manual mode under manual status.
- (2) Quality management: ,input defected quantity into corresponding order form based on orders,so good products quantity are able to supplement in time during production to insure pre-set good ones.

Chapter 4 production management

1. Set production Information



Press key , enter the menu for setting production information, now the menu is as following:

2016-05-17
 【production management】
 14:30:52

Setup mold number	one mold number	Output number	Good product	inferior product
4000	4	1000	3900	100

Qty reset
 Warning
 initial sequence no

OFF
 Disable
 0
 Next
 Return
 record clear

NO	Date	number	Output number	Good product	inferior product
1	08-15 10:16	4	1000	3900	100

Hint:0.OFF 1.ON

production management / production monitor / SPC Tracing record / incident track back



Description on setting parameters

- (1) The quality products equal to the number of the opened mold times the amount of one mold minus rejects. The rejects are controlled through ejecting testing function. When ejecting testing function is on, just like in stroke. When too much or too less stuff occurs, the rejects will increase amount value of one mould, and [Failure of plastic] alarms.
- (2). Set mold numbers: In the mold numbers setting of pre-production, the system starts alarming when the number of mold opening arrives at the first 5 molds till it reached The set output .
- (3). Warn Stop : [On] or [Off] can be selected. It will continue producing even arrives at the set mold number if [Off] has been selected till an operator stops it.
- (4).View method: a: move cursor to theup and downbutton to view, b, [initial sequence no display] : to locate by initial sequence no.and then use the up and down key to view.



Attention: Press key continuously to change production management page.

2. The output statistics iformation

Press  key to enter into flow chartand then Press  key enter the output statistics , now the menu is as follows:

2016-05-17

【 Output statistics 】

14:30:52

Search/Delete

Seach date

2016-06-29

Total

102

Last day

Clear intradate

Next day

Clear all

00-01	<input type="text" value="0"/>	06-07	<input type="text" value="0"/>	12-13	<input type="text" value="0"/>	18-19	<input type="text" value="0"/>
01-02	<input type="text" value="0"/>	07-08	<input type="text" value="0"/>	13-14	<input type="text" value="0"/>	19-20	<input type="text" value="0"/>
02-03	<input type="text" value="0"/>	08-09	<input type="text" value="0"/>	14-15	<input type="text" value="0"/>	20-21	<input type="text" value="0"/>
03-04	<input type="text" value="0"/>	09-10	<input type="text" value="0"/>	15-16	<input type="text" value="0"/>	21-22	<input type="text" value="0"/>
04-05	<input type="text" value="0"/>	10-11	<input type="text" value="0"/>	16-17	<input type="text" value="0"/>	22-23	<input type="text" value="0"/>
05-06	<input type="text" value="0"/>	11-12	<input type="text" value="0"/>	17-18	<input type="text" value="0"/>	23-24	<input type="text" value="0"/>

Hint:setup :0~100

production management

production monitor


SPC Tracing record

incident track back

Description on setting parameters

Computer provides function for production output statistics, system automatically record for past 15 days (per hour/per day production)

- (1) Inquiry/elimination: There are [Able]/[Disable] optional. Move cursor to [the day before],[the next day] and press [ENTER]to check the production data ofthe the day before or the next day; move cursor to [clear intraday output] and then press [ENTER] key to delete the query date output data,move cursor to [clear all data]and press [ENTER] key to delete all production output data.

Attention: Press  key continuously to change production management page.

3. SPC Tracing record information



Press  key three times, enter the into SPC Tracing record page which be as following:

2016-07-17
【SPC tracing record】
14:30:52

intermittent cycle 0 cycle 999
record item number 1
Page up
Page down
clear

NO	Date	Number	Cycle	Hidtrans	Hidtrans	Hidplace	Use	Fed place	Hid place	Mid open pl
10:16	1	15.16	0.50	0.50	0.50	0.48	50.05	50.05	50.05	50.05

Clear record

Max value										
Min value										
average value										
Deviation										


Hint:setup :0~100

production management
production monitor
SPC Tracing record
incident track back



Description on setting parameters

- (1). Record: the pagel has up to 999 pages, containing the consecutive information of the 999 modules. The SPC Tracing record system can provide up to 7 important parameters of the latest 999 modules. The operator can scroll up and down between page 1 and page 10 to manage the production of The modules. By using the system, the operator will be able to have more insight of the actual Variation of the important parameters and take specific and proper actions to adjust the system's operation and improve the quality of the product as a result.
- (2). Intermittent cycle: record the data once every several cycles.
- (3). View method: a: move cursor to the up and down button to view, b, [initial sequence no display]: to locate by initial sequence no. and then use the up and down key to view.



Attention: Press  key continuously to change production management page.

4. The Incident track back page

Press  key to enter into flow chart and then press  key to enter Incident track back page which will be as below:

2016-07-17

【SPC tracking record】

14:30:52

record data

0

display initial sequence NO

1

Page up

Page down

record clear

NO	User ID	Alarm time	Open mold Number	Incident
10:16	1	15.16	1	500.1

Hint:setup :0~100

production management


production monitor

SPC Tracing record



incident track back


Description on setting parameters

- (1).Display: there are 999 alarm records to be checked which provides convenience For equipment maintenance/repairing.
- (2).View method: a: move cursor to theup and down button to view, b, [initial sequence no display]: to locate by initial sequence no.and then use the up and down key to view.

Attention: Press  key continuously to change production management page.


5. The injection curve page

Press  key to enter into flow chart and then press  key to enter injection curve page which will be as below:



Description on setting parameters


- (1) Repetition times: acceptable to 1--4 times. It will display the latest curve data when selected one time, and it will display the last 4 times' curve data once 4 times is selected.
- (2) max pressure: the setup curve that the max pressure of left Y axis
- (3) max speed: the setup curve that the max speed of left Y axis
- (4) Pressure setup: [displayed] 【not displayed】 optional. Pressure curve will be displayed, not displayed on the contrary, It can be displayed six curves at the same time.

Attention: Press  key continuously to change curve management page.

6. The servo -real time curve page



Press CURVE key to enter into curve management, then Press INJECTION key enter the actual curve page , now the menu is as follows:



Description on setting parameters



- (1) Movement selection: there are "injection, 'feeding", mold-clamping, mold-opening"available. When injection was chosen.
- (2) Repetition times: acceptable to 1--4times. It will display the latest curve data when selected one time, and it will display the last 4 times? curve data once 4 times is selected.
- (3) Sampling cycle: the frequency that curve data adopts namely the interval time range: 0.1s--1.0s)
- (4) Left axis max: the setup curve that the max pressure of left Y axis
- (5) Right axis max: the setup curve that the max percentage of right Y axis
- (6) Pressure setup: [displayed] 【not displayed】 optional. Pressure curve will be displayed not displayed on the contrary, It can be displayed six curves at the same time.




Attention: Press CURVE key continuously to change curve management page.

7.the History curve page of servo page




Press  key to enter into curve management and then press  key to enter the curve page of servo history which the page will be as below:





Description on setting parameters


- (1)Data collection: There are **【start】** , **【stop】** available.Data collection be started, when selects **【start】** ,on the contrary, data collection will be stopped.
- (2)Sampling cycle: the frequency that curve data adopts namely the interval time range: 0.1s--1.0s)
- (3)Left axis max: the setup curve that the max pressure of left Y axis
- (4)Right axis max: the setup curve that the max percentage of right Y axis
- (5)Pressure setup:[displayed] **【not displayed】** optional.Pressure curve will be displayed, not displayed on the contrary, It can be displayed six curves at the same time.



Attention: Press  key continuously to change curve management page.


8.the temperature tracking curve page

Press  key to enter into curve management, then Press  key enter the tracking curve page , now the menu is as follows:



Description on setting parameters

- (1) Selection of display which is the historical tracking curve for checking on certain sections of temperature, temperature historical tracking record function of the system can provide the first 6 hours historical parameters for 6 sections of temperature and that enable operators master the change of machine actual inspection temperature better that lead to operators are able to make a comparison and analysis of affect to product quality by temperature.
- (2) Interval of sampling record: the time for sampling record interval ,5 minus.

Attention: Press  key continuously to change curve management page.


9.the temperature monitor page



Press CURVE key to enter into curve management and then press



EJE/CORE key to enter the temperature monitor which the page will be as below:



Description on setting parameters

parameter setup instruction:


- (1). use bar chart to show the relationship between actual temperature and setup temperature
- (2).show the heating output situation ,actual value ,setup value and status of every section of temperature




Attention: Press CURVE key continuously to change curve management page.

10.the injection speed curve page




Press  key to enter into curve management and then press



 key to enter injection speed


curve the page will be as below:



Description on setting parameters


- (1). Movement selection: there are "injection, 'feeding", mold-clamping, mold-opening"available. When injection was chosen.
- (2). Sampling cycle: the frequency that curve data adopts namely the interval time (range: 0.1 s--1.0s)
- (3). Left Y axis max: the setup curve that the max pressure of left Y axis
- (4). Right Y axis max: the setup curve that the max percentage of right Y axis
- (5). max speed: max speed of linear scale variation, this percentage data which is use current collected vary speed of to compare with max speed, range 1---60000
- (6). max speed: max displayed pressure value, this percentage data which is use current collected actual pressure to compare with max pressure, range 0---250
- (7). X axis is the biggest; setup the longest time for curve X axis




Attention: Press  key continuously to change curve management page.

11. USB setting page (for options)



Press  key; enter USB setting page. and it is as follows:



Parameter setting introduction

- (1) Formula downloading: download the mold data from control system of jet injection machine to the USB of moveable disc.
- (2) Formula uploading: upload the mould data from the USB of moveable disc to control system of jet injection machine; at the same time the data will overlay previous data correspondingly.
- (3) System downloading: download the mold data from control system of jet molding machine to the USB of moveable disc.
- (4) System uploading: upload the mould data from the USB of moveable disc to control system of jet moulding machine; at the same time the data will overlay previous data correspondingly.
- (5).Start/End D: when you are downloading the material of [formula] and [system], please designate the scope of the downloading data .
- (6).Mainframe replication: means updating the host procedures. First, press the stop button on the keyboard, then move the cursor to [replication], press the enter button and move the cursor to select [. Pin] files and update it.
- (7).Update OPWIN.PS6: means updating the keyboard procedures. Move the cursor to [update], press the enter button and move the cursor to select [. PS6] files and update it.
- (8).System value backups: **【factory value】** **【standard value】** .factory value comes from system backups(can be backupd based on customer' s demand).Standard value comes from system self -own parameters(fixed parameters can not be modified)
- (9).Frames activated setup as below:
 - (a).Picture play function: **【Disable】** **【Able】** optional.Normalpage will be displayed after system booting when selects **【disable】** ; and photo will be played after system booting when selects **【Able】**

- (b) photo uploading: 【addition】、【replacement】 optional. Only new photo will be added when Selects 【addition】 ; new photo will be added after deleted all exist photos when selects 【replacement】
- (c) Entering into normal page: 【counting reached】、【input】 optional. One photo will be automatically displayed after every interval time in [counting reach] mode; photos will be automatically played in turn after every interval time in [input] mode and then press [input] key to enter into normal page.

(D) photo message

Limit number: maximum 5 pieces of photo

Picture format: bmp only at present

Upload: the photo number which has been uploaded



Upload balance: the photo number which uploaded balance









LCD resolution ratio: max resolution ratio of photo

Picture setup		Return
photo function setup		
Picture play function	Disable	Able
photo uploading	Addition	Replacement
enter into normal page	Counting	Input
Loop playback times	1	interval time 1
photo message		
Limit number: 2	Picture format: BMP	
Upload: 2	Upload balance: 2	
LCD resolution : 1024*768		

1. Engineer Setting Page

2016-05-17	【Engineer setup】	14:30:52
F1 delay setup	★ cancellatin of login ★	Machine NO
F2 Pressure /flux slope		Ma300
F3 Pressure/Flow/Back pressure pre-adjustment		Controller NO
F4 Electronic ruler		PS860AM MK310
F5 sepcial Function setup		Software version
F6 Standby FunctionP rogrammable Standby		V2.0
F7 Temperature Parameter		
F8 Machine NoE x-FactoryValue Setting		

After the correct password is entered, the cursor jumps automatically to the first item from the right. The cursor can be moved to different items and then Key   is pressed to enter

Key	Entering Page	Key	Entering Page
	<Delay Setup>		<Standby Function Setting>
	<Pressure/Flow Setting I> <Pressure/Flow Setting II>		<Programmable Standby Points>
	<Pressure Pre-Adjustment> <Flow Pre-Adjustment>		<Temperature Parameter>
	<Special Function Options>		<Machine No./Ex-Factory Value Setting/Time Setting>

- (1) The meaning of Start Delay: the corresponding action valve ON → $\left[\begin{array}{l} \text{delay time T1} \rightarrow \text{pressure output ON} \\ \text{flow output ON} \end{array} \right]$
- (2) The meaning of End Delay: the corresponding action valve → $\left[\begin{array}{l} \text{pressure output OFF} \\ \text{flow output OFF} \end{array} \right] \rightarrow \text{delay time T2} \rightarrow \text{action valve OFF}$

3. Pressure/Flow Slope Setting Page

射出

Entering Engineer Setting Page, press Key INJECTION once to enter Pressure/Flow Slope Page I.
The following is displayed:

»Next 【Flow Slope Setup 1】 ↓ «Return Engineer

Action		P	F
slow mold close		16.0	16.0
Fast mold close		16.0	16.0
Low mold close		16.0	16.0
high pressure mold close		16.0	16.0
Slow mold open		16.0	16.0
Fast mold open		16.0	16.0
Middle mold open		16.0	16.0
Low mold open		16.0	16.0
Ejector advance Fast		16.0	16.0
Ejector advance slow		16.0	16.0

Action	P	F
ejector return	16.0	16.0
Core A in	16.0	16.0
Core A out	16.0	16.0
Core B in	16.0	16.0
Core B out	16.0	16.0
1 Level Injection	16.0	16.0
2 Level Injection	16.0	16.0
3 Level Injection	16.0	16.0
4 Level Injection	16.0	16.0
5 Level Injection	16.0	16.0

Hint:set range:1.0~16.0

Delay Slope Pre-adj. Ruler. Funtion. I/O transfer temp control factory setup

射出

Entering Engineer Setting Page, press Key INJECTION twice to enter Pressure/Flow Slope Page II.
The following is displayed:

»Next 【Flow Slope Setup 2】 ↑ «Return Engineer

Action	P	F
1 Level hold pressure	16.0	16.0
2 Level hold pressure	16.0	16.0
3 Level hold pressure	16.0	16.0
4 Level hold pressure	16.0	16.0
Front Suck back	16.0	16.0
1 Level feed	16.0	16.0
2 Level feed	16.0	16.0
Back Suck back	16.0	16.0
Nozzle advance	16.0	16.0
Nozzle return	16.0	16.0

Action	P	F
Mold thin	16.0	16.0
Mold thick	16.0	16.0
Core C in	16.0	16.0
Core C out	16.0	16.0
Core D in	16.0	16.0
Core D out	16.0	16.0
Standby		
Standby	1.0	1.0
Standby	1.0	1.0
Standby	1.0	1.0

Hint:set range:1.0~16.0

Delay Slope Pre-adj. Ruler. Funtion. I/O transfer temp control factory setup

Description on setting parameters

The Pressure/Flow Slope refers to the steep degree of rise or fall when the pressure/flow changes from one value to the next value. "0.1 stands for the slowest change and "16.0 stands for the fastest change. The setting range is .[0.1-16.0].

4. Pressure Pre-Adjustment Page

儲料
FEEDING

Entering Engineer Setting Page, press Key once to enter the Pressure Pre-Adjustment Page. The following is displayed:

»Next 【Pressure Pre-adjustment】 ↓ <<Return Engineer

minimum current 1000	Pre-adjust	Disable	80	23993	OFF
Flow pre-adjust 90.0 %	1	1 OFF	90	26992	OFF
initial data OFF	10	3000 OFF	100	29991	OFF
output current 0 mA	20	5999 OFF	110	31199	OFF
	30	8998 OFF	120	33128	OFF
	40	11997 OFF	130	39997	OFF
	50	14996 OFF	140	44996	OFF
	60	17995 OFF	150	47995	OFF
	70	20994 OFF	160	48000	OFF

Hint:set range:0~65535

Delay Slope Pre-adj. Ruler. Funtion. I/O transfer temp control factory setup

Description on setting parameters

The pressure pre-adjustment is the linear adjustment of pressure output. In general, the standard pressure is 0-800mA and the standard output impedance is 10-20Ω, unless the manufacturer has specific requirements since different manufacturers' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Pressure Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. First set the pre-adjustment to be [Activated], and then set the pre-adjustment item to be [ON]. For example, for the 50 bar Pressure position of Item 50, if the reading on the pressure meter is 45 bar, the parameter of this item should be increased until the pressure meter reading reaches 50 bar. Make adjustments on all parameters which need adjusting and make the 0-160 bar pressures being set correspond to the pressures being shown on the oil pressure meter respectively. After the adjustments are completed, the computer executes automatic linear processing and takes the processing results as the subsequent normal D/A proportional output values.

Initial data:

First, pre-adjust the needed maximum pressure data in 160bar, and then move the cursor to [initial data], press the enter key and select [ON], the system will automatically distribute average data to 10bar---160bar.

5. Flow Pre-Adjustment Page

Entering Engineer Setting Page, press Key 儲料
FEEDING twice to enter the Flow Pre-Adjustment Page. The following is displayed:

>>Next 【Flux Pre-adjustment】 ↓ << Return Engineer

minimum current 1000 Pressure pre-adjust 80.0 bar initial data OFF Initial data OFF pre-adjustment feeding OFF	Pre-adjust Disable 1 1 OFF 10 3600 OFF 20 7200 OFF 30 10800 OFF 40 14400 OFF 50 18000 OFF 60 21600 OFF	70 25200 OFF 80 28800 OFF 90 32400 OFF 99 36000 OFF
---	--	--

Hint:0.OFF 1.ON

Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer	temp control	factory setup
-------	-------	----------	--------	----------	--------------	--------------	---------------

Description on setting parameters

The flow pre-adjustment is the linear adjustment of flow output. In general, the standard value is 0- 800mA and the output impedance is 40 Ω, unless the manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different.

Flow Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. As for the speed adjustment, different manufacturers have different measuring methods. Some manufacturers use the melt tachometer to measure the rotation speed. First heat the barrel until the barrel temperature reaches normal melt temperature. Set the melt speed to be 1, 10, 20, 30, and more until 99 and check the actual values. Make adjustments on all parameters which need adjusting and make the 0-99% speeds being set correspond to the proportional coefficients being shown on the tachometer respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

Initial data:

First, pre-adjust the needed maximum flow data in 99%, and then move the cursor to [initial data], press the enter key and select [ON], the system will automatically distribute average data to 10%---90%.

6. Back Pressure Pre-Adjustment Page

儲料

FEEDING

Entering Engineer Setting Page, press Key third to enter the Back Pressure Pre-Adjustment Page. The following is displayed:

»Next 【Back pressure Pre-adjustment】 ↑ <<Return Engineer

coil resistance 12 Ω	Pre-adjust	Disable	80	23993	OFF
minimum current 80.0	1	1 OFF	90	26992	OFF
Maximum current OFF	10	3000 OFF	100	29991	OFF
initial data OFF	20	5999 OFF	110	31199	OFF
	30	8998 OFF	120	33128	OFF
	40	11997 OFF	130	39997	OFF
	50	14996 OFF	140	44996	OFF
	60	17995 OFF	150	47995	OFF
	70	20994 OFF	160	48000	OFF

Hint:set range:0~65535

Delay Slope Pre-adj. Ruler. Funtion. I/O transfer temp control factory setup

Description on setting parameters

The back pressure pre-adjustment is the linear adjustment of back pressure output. In general, the standard pressure is 0-800mA and the standard output impedance is 10-20Ω, unless the Manufacturer has specific requirements since different manufactures' overall oil piping designs and the capabilities of the pressure proportional valve being used are different

Back Pressure Adjustment Method:

The parameters on this page have been set before ex-factory. If the capability of the proportional valves being used by the user is different, and the normal proportion and linear proportion cannot be achieved, the parameters on this page can be adjusted. First heat the barrel until the barrel temperature reaches normal melt temperature. Set the melt back pressure to be 1, 10, 20, 30, and more until 160 and check the actual values. Make adjustments on all parameters which need adjusting and make the 0-160bar back pressures being set correspond to the back pressures being shown on the back pressure meter respectively. After the adjustments are completed, the computer executes automatically linear processing and takes the processing results as the subsequent normal D/A proportional output values.

Initial data:

First, pre-adjust the needed maximum pressure data in 160bar and then move the cursor to [initial data], press the enter key and select [ON], the system will automatically distribute average data to 10bar---160bar.

7. Electronic Ruler.Pressure text Setting Page

座臺/調模

Entering Engineer Setting Page, press Key NOZZ/ADJ. once/twice enter the Electronic Ruler/ Pressure Setting Page. The following is displayed:

»Next

Electronic ruler 1

Return Engineer

Ruler Function	measure value	Total	limit position	set zero
AD1/2 Moveable	Enable 593.9	600.00	600.00	OFF
AD3/4 Screw	Enable 235.75	600.00	600.00	OFF
AD5/6 Ejector	Disable *****	*****	*****	OFF
AD7/8 Nozzle	Disable *****	*****	*****	OFF

AD1/2

AD3/4

AD5/6

AD7/8

Hint:0.disable 1.enable

Delay Slope Pre-adj. Ruler Function I/O transfer temp control factory setup

»Next

pressure test setup

Return Engineer

Ruler Function	value	Maximum up limit	set zero
Mold close	Enable *****	*****	OFF
Screw	Disable 235.75	300.00 200.00	OFF

AD1/2

AD3/4

AD5/6

AD7/8

Hint:0.OFF 1.ON

Delay Slope Pre-adj. Ruler Function I/O transfer temp control factory setup

»Next

Electronic ruler 2

Return Engineer

Ruler Function	measure value	Total	limit position	set zero
AD1 Moveable	Enable 593.9	600.00	600.00	OFF
AD3 Screw	Enable 235.75	600.00	600.00	OFF
AD5 Ejector	Disable *****	*****	*****	OFF
AD7 Nozzle	Disable *****	*****	*****	OFF

AD1

AD3

AD5

AD7

Hint:0.disable 1.enable

Delay Slope Pre-adj. Ruler Function I/O transfer temp control factory setup

»Next

Electronic ruler 3

Return Engineer

Ruler Function	measure value	Total	limit position	set zero
A1/B1 Moveable	Enable 593.9	600.00	600.00	OFF
A2/B2 Screw	Enable 235.75	600.00	600.00	OFF
A3/B3 Ejector	Disable *****	*****	*****	OFF
A4/B4 Nozzle	Disable *****	*****	*****	OFF

A1/B1

A2/B2

A3/B3

A4/B4

Hint:0.disable 1.enable

Delay Slope Pre-adj. Ruler Function I/O transfer temp control factory setup

Description on setting parameters

- Electronic Ruler Function: If the equipment needs to use the electronic ruler, choose [Enable].If the equipment adopts stroke switch control, choose [Disable].
- Measurement Values: indicating the actual dynamic positions of the electronic rulers for the moving mould, the screw and the ejector.
- Total Length: referring to the actual lengths of the electronic rulers for the moving mould, the screw and the ejector.
- Limit Position: It refers to the maximum value set for the position. This parameter is subject to the maximum position setting. For example , if the parameter set is bigger than the limit position value, the system will not accept the parameter set and will retain the original setting.
- Zeroing: When the equipment choose [Enable] for the Electronic Ruler Function and uses the Electronic ruler, it may appear that the mechanic movement stroke is in place and yet the actual positions of the electronic rulers for the clamping unit, the injection unit and the ejector do not Indicate "0". In such case, the corresponding ruler should be zeroed. Move the cursor to the Zeroing button for [movable mold ruler], [screw ruler] and [ejector ruler], and then press 輸入 ENTER Key to make zero clearing for the corresponding electronic ruler.
- Sensor function, maglev ruler, double-ruler setup: setup method same as electronic ruler。Special instruction: maglev ruler (unit: m/s) is one signal of transmission speed in waveguide tube, each pieces of maglev ruler' s transmission speed is different, please fill with correct data from the maglev ruler 's sticker so not to affect its accuracy. Attention: strongly recommends double-channel of ruler (refer to appendix)

8. Special Function Options Page

托模/中子

EJE/CORE

Entering Engineer Setting Page, press **EJE/CORE** Key to enter the Special Function 1 Options Page. The following is displayed:

»Next		【Chose special function 1】		↓		«Return Engineer	
motor idle auto stop	Disable	mold open stop range	5.0	mm			
motor idle time limit	1	M	Core start method	travel			
motor Y-△conversion	Disable	Ejector end method	Timel				
motor Y-△conversion time	2.0	Mold adjust drive	Hydraulic				
motor △forward delay	0.1	Blow begin	travel				
Motor start delay	3.0	Heater limit	Disable				
Manual Nozzle advance limit	Disable	Feed single ring teeth number	1				
Feed with mold open	Disable	High Temperature alarm	Disable				
Feed with key lock	Disable	injector Protective cover	Enable				
Hint:0.disable 1.enable							
Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer	temp control	factory setup

Descriptions on setting parameters function mode

- (1) Motor Idle Running & Automatic Stop: When [Enable] is chosen, time setting is effective and the setting range is 2-99 minutes. If the equipment has no operation within the set time period after the motor starts up, the motor is turned off automatically to protect the motor life and to save electricity charge.
- (2) Motor Y-△Conversion: If [Enable] is chosen, the system converts from star output to delta output when the motor starts up. The conversion time period can be set and the setting range is 2.0-99.9 seconds.
- (3) Motor Startup Delay: After the motor starts, no manual/auto operation can be conducted until the set time is delayed.
- (4) Manual Base Advance Limit: If deactivated, the injection base advance is not subject to stroke control. If activated, the injection base advance position is subject to the control of the limit switch X06.
- (5) Mould Opening with Melt: If activated, the mould opening can be done as soon as the cooling time expires, even if the melt has not finished taking out.
- (6) Melt Key Locking: If activated, press the melt key once and then the melting continues and will stop when the melt position is reached or the time expires. Or press the melt key once more to stop the melting.
- (7). Neutron beginning methods: select [travel] or [position], select [position] to set the position value, and the Movements when the dynamic mode arrives; select [travel], select the starting movements from the four options of dynamic mode trip.
- (8). The Core start method: select [position] or [travel], start the blowing work at the dynamic mode position or the trip conditions in automatic state.
- (9) Ejector Stop Type: [Stroke] or [Time] can be chosen. If [Stroke] is chosen, the stop is subject to the stroke. If [Time] is chosen, the stop is subject to the set time.

- (10) Mould Adjustment Activation: [Hydraulic] or [Electric] can be chosen. When [Hydraulic] is chosen, mould adjustment pressure and speed do not participate in the mould adjustment job.
- (11) Begin Blowing: Choose [Location] or [Travel], then the machine will blow in the mold moving location or travel conditions in automatic mode.
- (12) Electric Heating Restrict: Choose [Disable] or [Enable], in [Enable], the electric heating will not be started in the process of motor start, but will in [Disable].
- (13) Stock Single Ring Gear No.: The number of the gears around the screw.
- (14) High Temperature Alarm Function: Choose [Disable] or [Enable], when in [Enable] and the actual temperature is beyond the upper limit; ? in the automatic state, alarm [High Temperature] and ejection, stock and withdrawal will not act; ? in manual state, ejection, stock and withdrawal will continue working. In [Disable], all actions will not be affected by temperature upper limit.
- (15) Ejection Protective Boot Function: Choose [Disable] or [Enable], when in [Enable] and the ejection, stock and withdrawal act and X02 is OFF, the system will alarm with [Ejection Protective Boot not Closed] and there is no action output; on the contrary, the action will not be affected by Xo2 state.

托模/中子

Entering Engineer Setting Page, press  Key twice to enter the Special Function 2 Options Page. The following is displayed:

»Next		【Chose special function2(upper limit)】		»Return Engineer	
mold clamping pressure	30.0	Nozzle pressure	160.0	injection pressure	160.0
mold clamping flow	20.0	Nozzle flux	99.0	Injection flux	99.0
mold opening pressure	160.0	Mold adjust pressure	160.0	Feed pressure	160.0
mold opening flow	99.0	Mold adjust flux	99.0	Feed flux	99.0
mold clamping high pressure	160.0	Ejector pressure	160.0	Back pressure	160.0
mold clamping high pressure flow	99.0	Ejector flux	99.0	Temperature upper limit	600.0
open/close mold pressure	30.0	core pressure	160.0	Temperature Percent	100.0
open/close mold flow	20.0	Core flux	99.0	Standby	****
Hint:set range:0.0~160.0					
Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer
temp control		factory setup			

Function parameter setting introduction

- (1) Pressure/flux upper limit: the setting value in this page will lie on the upper limit range for setting values of mold parameter in every page.
- (2). Maximum temperature/ percentage: the scope of maximum temperature setup value.

托模/中子

EJE/CORE

Entering Engineer Setting Page, press  Key third time to enter the Special Function3 Options Page. The following is displayed:


»Next		【Chose special function 3】		↓		« Return Engineer	
first mold lubrication function	Disable	base forward valve of manual injection	Disable				
lubricate intermittent	Enable	servo function	Enable				
Lubricate mold number upper limit	200	ejector finish in sensor mode	Times				
Lubricate timing lower limit	3.0	electric heat auto off once temp exceeds limit	Enable				
oil lack output limit	Disable	Injection failure switching to manual automatically	Disable				
oil lack delay alarm	2.0	nitrogen function	Disable				
Cool water	Disable	nitrogen recharging delay	0				
Cool water delay	1.0	lubricat again function	Enable				
safe door control mode	Mode 1						
rear safe door close motor	motor stop						
Hint:0.disable 1.enable							
Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer	temp control	factory setup

Function parameter setting introduction

- (1) First mold lubrication: select [Enable], lubricate once when the motor is from close to open and first molding. or it will not lubricate.
- (2) Interval lubrication: can select [Enable] or [Disable], it will lubricate no intervals when select [Disable], it will lubricate intervals when select [Enable]
- (3) Maximum lubricating mold number: The maximum number of lubricating mold, it is used to control lubricating cycle
- (4) Minimum lubricating time: The minimum time of lubricating
- (5) lack of oil delay alarm: select [Enable] it will alarm when the input time in the lack of oil delay alarm X32 is up
- (6) Water cooling: select [Enable], the cooling water switch is ON in normal state, and it will alarm "the switch of cooling water is not open" until setting time is up
- (7) safety door control mode: can select [mode 1] or [mode 2], select [mode 1] front safety door: X00, X01, back safety door: X15, X16 (back safety door control motor), select [mode 2] front safety door: X0, back safety door: X15 (please refer to safety door diagram I, II)
- (8) Back Safety Door Open: Choose [Stop Motor] or [Disable]. If the [Safety Door Control Mode] chooses [Mode 1], the [Back Safety Door] function will be valid. When [Stop Motor] is chosen, if the rear safety door X15 or X16 is OFF, the system will alarm with [Rear Safety Door Not Closed] and the motor will stop; on the contrary, only alarm without stopping the motor.
- (9) Base forward valve of Manual injection: there are [Enable] or [Disable] can be selected, when select manual state is [Enable], signal of base forward-stop is on, Y1 is outputted and there is injection movement, conversely no output.
- (10) Servo function: there are [Enable] or [Disable] can be selected, the relevance pages will be displayed when selecting [Enable], conversely no display.

- (11) Electric heating off when Temperature exceeds upper limit: there are **【enable】** and **【disable】** available. Under enable status, when the actual detection temperature is above its upper limit, turn off heating function and alarms: temp detection exceeds set upper limit, otherwise no need to do it.
- (12) Ejector finished under sensor status: there are **【sensor detection finished】** and **【times of ejector reached】** available. When under sensor auto mode and when choosing **【sensor detection finished】** times of ejector not reached but sensor detection okay, system will go to next cycle by ejector finished; and when choosing **【times of ejector reached】** namely even sensor detection okay, it have to wait for times of ejector finished and then go to next cycle.
- (13) Nitrogen function: there are **【enable】** and **【disable】** available. When choosing **【enable】**, turn on motor and motor delayed time reached---nitrogen charging delay?---time---time is up--proceed to charging/releasing nitrogen.
- (14) Injection failure switching to manual mode: there are **【enable】** and **【disable】** available. When choosing **【enable】**, under auto mode, if injection failure alarms and switch to manual mode; otherwise only alarms no switching to manual mode.
- (15) Relubricating function: there are **【enable】** and **【disable】** available. When choosing **【enable】**, while lubricating failure alarms (malfunction elimination) please lubricate again, it stops alarming when detection signal from relubricating movement.

Entering into engineer page and then press



4 times for special function page 4 which will be as following:

»Next		【Chose special function 4】		↓		«Return Engineer	
auto door function	Disable	manual key lock automatically	Disable				
safe door drives	Hydraulic	open-door position	Front				
		door open automatically delay	0.00			s	
		open-door stop mode	Time				
		door open automatically	0.00			s	
		safe door open pressure	160.0			bar	
		safe door open flow rate	99.0			%	
		safe door close pressure	160.0			bar	
		safe door close flow rate	99			%	
Hint: 0.disable 1.enable							
Delay	Slope	Pre-adj.	Ruler	Funtion.	I/O transfer	temp control	factory setup

- (1) Auto safe door function: there are **【enable】** and **【disable】** available. When choosing **【enable】**, the open or close action is being done by actuator, conversely, need manual.
- (2) Safe door drives: there are **【hydraulic】** and **【motor-driven】** available, when choosing **【motor-driven】** to adjust pressure, speed not participate in the door open/close movement; conversely working.

- (3) Door-opening stop mode: there are **【time】** and **【distance】** available, when choosing **【time】**, one of the time or distance to open-stop completed and then safe door open movement; when choosing **【distance】**, use distance to finish and safe door open movement
- (4) Safe door key lock automatically: there are **【enable】** and **【disable】** available, when choosing **【enable】** inching keys of open door or close door for door opening or door closing, and press again for movement stop; otherwise press for movement and release for movement stop.
- (5) Door open starting position: there are **【pre-mold opening】** **【mold open stop】** and **【ejector Finisheed】** available. When choosing **【pre-mold opening】** under semi-atuo mdoe and mold open movement, s door open, same to others.
- (6) Door open start delay: time begin to count before safe door runs, and when time is up then proced to door open.

9. Servo Driver monitor Setup Page



Press **MONITOR** key to enter the servo driver setup page with the display as follows:

2012-02-09

【Servo Driver Monitoring Parameters】

12:02:09

Servo Driver NO	AG2011RA				
Operation Status	Normal				
servo connection status	servo driver is offline				
Driver Temperature	35.6℃	Motor Temperature	36.1℃		
Pressure Setup	140.0 Bar	Output Current	2.5	A	
Pressure Feedback	20.0 Bar	Output Torque	7	Nm	
Flow Setup	99.9 %	Motor rated Speed	140	Rpm	
Flow Output	30.0 %	power output	300	Kw	

Hint:0.disable 1.enable

Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer	temp control	factory setup
-------	-------	----------	--------	----------	--------------	--------------	---------------

10. Servo Driver Setting Page

托模/中子

Enter the engineer page, press EJE/CORE key to enter the setup page with the display as follows:

»Next 【On-Line Parameters】 << Return Engineer

on-line mode selection On-line Operation Hint Ready

No. of pump while on-line machine	2		mini speed of sub-machine	1	
displacement of main machine pump	5	mL/r	displacement of sub-machine pump 5	1	mL/r
displacement of sub-machine pump 1	1	mL/r	displacement of sub-machine pump 6	1	mL/r
displacement of sub-machine pump 2	1	mL/r	displacement of sub-machine pump 7	1	mL/r
displacement of sub-machine pump 3	1	mL/r	displacement of sub-machine pump 8	1	mL/r
displacement of sub-machine pump 4	1	mL/r	displacement of sub-machine pump 9	1	mL/r

Hint:0CAN 1.0~10V

F1 Delay F2 Slope

»Next 【Selection V-Type Selection Parameters】 << Return Engineer

Base Pressure	2.0	System Response Proportion	75
Base Flow	2.0	System Response Integral	5
Pressure Adjustment Slope	30	System Response Differential	90
Flow Adjustment Slope	30	System Response Time	10
Torque Overload Multiple	50	Pressure Discharge Reverse Speed Limit	5.0
Pump Swash Plate Switching Value	100	Reverse Max. Torque	10

Hint:set range:0.0~20.0

Delay Slope Pre-adj. Ruler. Funtion. I/O transfer temp control factory setup

>>Next
 multi- group PID selection
 << Return Engineer

Mold closing slowly/fastly	0	storing 1	0
low pressure mold closing	0	storing 2	0
high pressure mold closing	0	injection retreat	0
Mold opening slowly	0	ejector forward	0
level 1 injection	0	ejector return	0
level 2 injection	0	Core	0
pressure maintaining	0	mold adjustment	0

Hint:set range:0.0~20.0

Delay
 Slope
 Pre-adj.
 Ruler.
 Funtion.
 I/O transfer
 temp control
 factory setup



Press key to enter into diagnose then Press key enter the Servo alarm record,now the menu is as follows:



2016-07-17
 Servo alarm record
 14:30:52

record data 0
 display initial sequence NO 1
 Page up
 Page down
 record clear

sequence no	Alarm time	NO	Alarm	sequence no	NO	Current	Speed
10:16	1	15.16	1				

Hint:setup :0~100

Delay
 Slope
 Pre-adj.
 Ruler.
 Funtion.
 I/O transfer
 temp control
 factory setup

Note: The above is the page of the related parameters of the servo driver. Please refer to [User Manual of ServoDriver] for details.

11. Standby Function Setting Page

After entering the correct password, press  Key to enter the Standby Function Setting Page. The following is displayed:

>>Next 【Standby Function】 ↓ << Return Engineer

Y	6	→	Y	26	ON
Y	0	→	Y	0	OFF
Y	0	→	Y	0	OFF
Y	0	→	Y	0	OFF
X	25	→	X	0	ON
X	5	→	X	10	ON
X	0	→	X	0	OFF
X	0	→	X	0	OFF

Hint:0.OFF 1.ON

Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer	temp control	factory setup
-------	-------	----------	--------	----------	--------------	--------------	---------------

Descriptions on setting parameters function mode

- (1) Output Point Transfer Function: This function canbe enable or disable. If enable, the output point executes immediately transfer operation. In case that mal-function or damage occurs to a certain point, the control can betransferred to another point by activating this function. For example, in case that failure occurs to the mould opening output point and the knockout core function is disable, theY06 mould opening pointcan be transferred toY26 and then the output wires should be exchanged. The system is equipped with the function of simultaneously transferring two output points. Once this function is enable, the system makes judgment on the two selected items. If the item is [ON], the transfer of thepre-set conditions of the item will be executed.
- (2) Input Point Transfer Function: This function can be enable or disable . If enable, the input point Executes immediately transfer operation. In case that mal-function or damage occurs to a certain point, the control can be transferred to another point by activating this function. For example, in case that failure occurs to thefront safety door input point and theknockout core function is disable, the X00 front safety door input point can be transferred to X25 and then the input wires should be exchanged. The system is equipped with the function of simultaneously transferring two input points.once this function is enable, the system makes judgment on the two selected items. If the item is[ON], the transfer of the pre-set conditions of the item will be executed.

12. Programmable Standby Function Page

After entering the correct password, press

時間
TIME

 Key to enter the Programmable Page. The following is displayed:

>>Next

【Programmable Standby Function】

↑

<<Return Engineer

Enable	Y	4	AT	CD	Segment out
Enable	Y	6	AT	FH	Segment out
Disable	Y	0	AT		Segment out
Disable	Y	0	AT		Segment out
Disable	Y	0	AT		Segment out

A=fast mold close B=low pressure C=high pressure D=mold close stop
E=nozzle advance F= injection advance G=hold pressure H=feed
I= injection return J=nozzle return K=mold open slow L=fast mold open
M=low mold open N=ejector O=core P=mold adjecte

Hint:set range :0~77

Delay

Slope

Pre-adj.

Ruler.

Funtion.

I/O transfer

temp control

factory setup

Descriptions on setting parameters function mode

In order to meet diversified application needs and provide an innovative product, we take the Initiative to offer the programmable standby function page so that the users can define and revise by themselves the functions and the action sequence.

Example 1: For a certain mould injection machine, due to the different design of the oil piping, it is required that a point is output while clamping at high pressure and the power will not be interrupted until the melt finishes taking out. To achieve such a special function, choose an item and have it activated, and then specify an output point (i.e. this function is output through Y01), and then set the action sequence [CD].

Notes: Regarding the output scope of Sequence D Clamping Stop, in automatic mode, the Clamping switch is contacted during the process of mould close at high pressure, and this sequence output starts until the melting finishes; in manual mode, the clamping switch is contacted during the process of mould close at high pressure, and this sequence output starts until the mould opening key or the reset key is pressed.

Example 2: For a certain mould injection machine, due to the different design of the oil piping, it is required that a point is output while injecting and melting. To achieve such a special function, Choose an item and have it activated, and then specify an output point (i.e. this function is output through Y22), and then set the action sequence [FH].

13. Temperature ParameterSetting Page

After entering the correct password, press Key  to enter the Temperature Parameter Setting Page. The following is displayed:

»Next 【 temp control parameter 】 << Return Engineer

	Function	P	D
Ejector	Enable	100	200
1 Segment	Enable	100	200
2 Segment	Enable	100	200
3 Segment	Enable	100	200
4 Segment	disable	100	200
5 Segment	Disable	100	200
K 6 Oil Temperature Alarm			Disable
Oil Temperature upper limit			60.0

	Function	P	D
EK0	Enable	0	0
EK1	Enable	0	0
EK2	Enable	0	0
EK3	Enable	0	0
EK4	Enable	0	0
EK5	Enable	0	0
EK6	Enable	0	0
EK7	Enable	0	0
EK8	Enable	0	0
EK9	Enable	0	0
EK10	Enable	0	0
EK11	Enable	0	0

Hint:set range :0~300


Delay Slope Pre-adj. Ruler. Funtion. I/O transfer temp control factory setup

function Description on setting parameters

- (1) Ejector Function、1Segment、2Segment、3Segment、4Segment、5Segment function、[Activated]or [Deactivated] can be chosen. If deactivated,the system will not execute inspectionand controlon this sequence.
- (2) Oil Temperature Alarm: [Activated] or [Deactivated] can be chosen. Ifdeactivated, once it is detected
- (3) Pd Setting: Pd has been set before ex-factory. It is recommended that the user should not revise this parameter under normal circumstance.
- (4) Proportion control: proportion control is one of the simplest way for controlling, in which the input error signals are in proportion relation with output signals. There are steady-state errors when proportion control is the only way to be utilized.
- (5) Different coefficient control: in different coefficient control, output error signals of controller form direct proportion relationship with input error signals of controller Fluctuation even destabilization may appear in automatic control system during the course of getting over and adjusting errors. The reason is: the existing heavier inert (links) or lagging assemblies can constrain errors, and its changing is always behind the changing of errors.The solution is to make the changing of errors constraint effect become advancing, i.e., the errors constraint effect should be zero when errors become close to zero. That is, it is notefficient enough to introduce proportion into controller merely. The function of Proportion can only enlarge the amplitude value oferrors. But at present time itis necessary toin crease different coefficient , which can forecast the changing directions ofthe errors. Thecontroller combined proportion with different coefficient cancause errors constraint effect to bezero, even to be negative,thereby severe over adjusting ofproportion under controlling can be avoided. So for Assemblies under controllingwith heavier inertiaor lagging, PDcontroller can improve dynamic behaviors of systemduring adjustment.

14. Machine No./Ex-Factory Value/Time Setting Page

After entering the correct password, press Key **資料 DATUM** to enter the Machine No./Ex-Factory Value/Time Setting Page. The following is displayed:



【Machine No./Ex-Factory Value】 << Return Engineer

Machine No	Input conversion
M3	ABC enter
Controller No	timer to zero
PS860AM/MK310	Confirm
Soft ware version	System Backup value
V2.2	Confirm
	Ex-Factory Value Restoration
	Confirm
	Password management
	enter >>
	★ Super password ★

TUE 2016-04-25 15:30:40

Hint:1-12


Delay	Slope	Pre-adj.	Ruler.	Funtion.	I/O transfer	temp control	factory setup
-------	-------	----------	--------	----------	--------------	--------------	---------------

Descriptions on setting parameters function mold

- (1) Machine No: The system is equipped with the function of setting NO. for the mould injection machine so that the manufacturer can set the No. for easy sales management and after-sales service record.
- (2) Ex-Factory Value Restoration: During the modifying process of password pages, if normal operation cannot be achieved due to too much deviations of the modified parameters, press Key Enter and choose Confirm, and then all the contents and all the parameters will be restored to the standards values set before ex-factory.
- (3) System Backup value: standard values backup are provided for resetting when machines leave factory;
- (4). Time setup: to setup the time, after the setup, press the [input] key, and then press [OK], the update is successfully set up.

Chapter 6 Input/Output Mode Inspection

1. Alarm history page

Press  key , to enter the alarm history page, and it is as follows:

2016-05-17 【Alarm history】 14:30:52

record item number Display start number page up page down record clear

sequence no	Alarm Time	Number	Alarmmatter
16 10:06	16 10:06	64	Temperature higher cycle time over
16 10:13	16 10:13	21	

Alarm Input Output Key test AD test Servo alarm

Description on setting parameters

- (1). Display: the system stores at most 999 pieces of alarm records for inspection, it will be helpful for the maintenance of the equipments.
- (2).View method: a: move cursor to theup and downbutton to view, b, [initial sequence no display]: to locate by initial sequence no.and then use the up and down key to view.

2. Input Inspection Page

- (1) Press **2_{VWX}** Key on the Main Page to enter Input Inspection Page 1 and the following will be displayed:

2016-05-28		【Input check 1】		16:33:30	
<input type="checkbox"/> X00 front door 1	<input type="checkbox"/> X10 lubricating oil is low				
<input type="checkbox"/> X01 front door 2	<input type="checkbox"/> X11 lubricating press is low				
<input type="checkbox"/> X02 injector Protective cover	<input type="checkbox"/> X12 safe valve detection				
<input type="checkbox"/> X03 mold close stop	<input type="checkbox"/> X13 Ejection before stop*				
<input type="checkbox"/> X04 Electric Eye enter	<input type="checkbox"/> X14 Ejection return stop *				
<input type="checkbox"/> X05 feed rotation speed	<input type="checkbox"/> X15 back door 1				
<input type="checkbox"/> X06 before nozzle stop*	<input type="checkbox"/> X16 back door 2				
<input type="checkbox"/> X07 after nozzle stop *	<input type="checkbox"/> X17 safe door really				
Machine run well		mold close slow			
Alarm	Input	Output	Key test	AD test	Servo alarm

- (2) Press **3_{YZ}** Key on the Main Page to enter Input Inspection Page 2 and the following will be displayed:

2016-05-28		【Input check 2】		16:33:30	
<input checked="" type="checkbox"/> X20 fine adjust teeth number	<input type="checkbox"/> X30 core A advance /Count				
<input type="checkbox"/> X21 front mold adjust stop	<input type="checkbox"/> X31 core A return				
<input type="checkbox"/> X22 back mold adjust stop	<input type="checkbox"/> X32 core B advance/Count				
<input type="checkbox"/> X23 mechanic hand mold close	<input type="checkbox"/> X33 core B return				
<input type="checkbox"/> X24 mechanic hand ejector	<input type="checkbox"/> X34 core C advance/Count				
<input type="checkbox"/> X25 mold area	<input type="checkbox"/> X35 core C return				
<input type="checkbox"/> X26 door open stop	<input type="checkbox"/> X36 core D advance/Count				
<input type="checkbox"/> X27 motor fault	<input type="checkbox"/> X37 core D return				
<input type="checkbox"/> X40 nitrogen upper limit	<input type="checkbox"/> X42 Cooling water				
<input type="checkbox"/> X41 nitrogen down limit					
Machine run well		mold close slow			
Alarm	Input	Output	Key test	AD test	Servo alarm

3. Key Inspection Page

- (1) Press **4_{JKL}** Key on the Main Page to enter Key Inspection Page I and the following will be displayed:

2016-05-28		【Key check 1】		16:33:30	
<input type="checkbox"/>	M00 manual	<input type="checkbox"/>	M08 charge		
<input type="checkbox"/>	M01 Semi-automatic	<input type="checkbox"/>	M09 auto purge		
<input type="checkbox"/>	M02 Electric Eye auto	<input type="checkbox"/>	M10 mold chose		
<input type="checkbox"/>	M03 time auto	<input type="checkbox"/>	M11 injection manual		
<input type="checkbox"/>	M04 heater on/off	<input type="checkbox"/>	M12 injection suck back		
<input checked="" type="checkbox"/>	M05 motor on/off	<input type="checkbox"/>	M13 blow male manual		
<input type="checkbox"/>	M06 open mold manual	<input type="checkbox"/>	M14 blow female manual		
<input type="checkbox"/>	M07 close mold manual	<input type="checkbox"/>	M15 mold thick manual		
Machine run well				mold close slow	
Alarm	Input	Output	Key test	AD test	Servo alarm

- (2) Press **5_{MNO}** Key on the Main Page to enter Key Inspection Page 2 and the following will be displayed:

2016-04-28		【Key check 2】		16:33:30	
<input type="checkbox"/>	M16 mold thin manual	<input type="checkbox"/>	M24 ejector manual		
<input type="checkbox"/>	M17 ejector return manual	<input type="checkbox"/>	M25 core C in manual		
<input type="checkbox"/>	M18 ejector advance manual	<input type="checkbox"/>	M26 core C out manual		
<input type="checkbox"/>	M19 lubricate manual	<input type="checkbox"/>	M27 core B in manual		
<input type="checkbox"/>	M20 ejector manual	<input type="checkbox"/>	M28 core B out manual		
<input type="checkbox"/>	M21 core A in manual	<input type="checkbox"/>	M29 data lock		
<input type="checkbox"/>	M22 core A out manual	<input type="checkbox"/>	M30 emergency stop		
<input type="checkbox"/>	M23 lubricate manual	<input type="checkbox"/>	M31		
Machine run well				mold close slow	
Alarm	Input	Output	Key test	AD test	Servo alarm

(3) Press **6**_{PQR} Key on the Main Page enter A/Dcheck and the following will be displayed:

2016-05-18	【A/D check】	16:33:30
<div><input checked="" type="checkbox"/> K0 eject temperture</div> <div><input checked="" type="checkbox"/> K1 1Segment temperture</div> <div><input checked="" type="checkbox"/> K2 2Segment temperture</div> <div><input checked="" type="checkbox"/> K3 3Segment temperture</div> <div><input checked="" type="checkbox"/> K4 4Segment temperture</div> <div><input checked="" type="checkbox"/> K5 5Segment temperture</div> <div><input checked="" type="checkbox"/> K6 oil 1temperture</div>		
Machine run well		mold close slow
Alarm	Input	Output
Key test	AD test	Servo alarm

4. Output Inspection Page

(1) Press **7**_{ABC} Key on the Main Page to enter Output Inspection Page 1 and the following will be displayed:

2016-05-18	【Output check 1】	16:33:30
<div><input checked="" type="checkbox"/> Y00 mold close</div> <div><input type="checkbox"/> Y01 nozzle advance</div> <div><input type="checkbox"/> Y02 injector</div> <div><input type="checkbox"/> Y03 feed</div> <div><input type="checkbox"/> Y04 suck back</div> <div><input type="checkbox"/> Y05 nozzle return</div> <div><input type="checkbox"/> Y06 mold open</div> <div><input type="checkbox"/> Y07 ejector advance</div>	<div><input type="checkbox"/> Y10 ejector return</div> <div><input type="checkbox"/> Y11 mold thin</div> <div><input type="checkbox"/> Y12 differential mold locking</div> <div><input type="checkbox"/> Y13 mold thick</div> <div><input type="checkbox"/> Y14 mold open buffer</div> <div><input type="checkbox"/> Y15 fault alarm</div> <div><input type="checkbox"/> Y16 low pressure mold close</div> <div><input type="checkbox"/> Y17 high pressure mold close</div>	
Machine run well		mold close slow
Alarm	Input	Output
Key test	AD test	Servo alarm

- (2) Press **8_{DEF}** Key on the Main Page to enter Output Inspection Page 2 and the following will be displayed:

2016-05-28		【Output check 2】		16:33:30	
<input type="checkbox"/>	Y20 mold open finished	<input type="checkbox"/>	Y30 core A out		
<input type="checkbox"/>	Y21 ejector finished	<input type="checkbox"/>	Y31 core B in		
<input type="checkbox"/>	Y22 fully auto	<input type="checkbox"/>	Y32 core B out		
<input type="checkbox"/>	Y23 nitrogen recharge	<input type="checkbox"/>	Y33 core C in		
<input type="checkbox"/>	Y24 nitrogen release	<input type="checkbox"/>	Y34 core C out		
<input type="checkbox"/>	Y25 blow male	<input type="checkbox"/>	Y35 core D in		
<input type="checkbox"/>	Y26 blow female	<input type="checkbox"/>	Y36 core D out		
<input type="checkbox"/>	Y27 core A in	<input type="checkbox"/>	Y37 big pump		
<input type="checkbox"/>	Y40 door open	<input type="checkbox"/>	Y42 middle pump		
<input type="checkbox"/>	Y41 door close				
Machine run well				mold close slow	
Alarm	Input	Output	Key test	AD test	Servo alarm

- (3) Press **9_{GHI}** Key on the Main Page to enter Output Inspection Page 3 and the following will be displayed:


2016-05-28		【Output check 3】		16:33:30	
<input type="checkbox"/>	T0 ejector temperature	<input checked="" type="checkbox"/>	Manual indicate		
<input type="checkbox"/>	T1 1Segment temperature	<input type="checkbox"/>	Semi-automatic		
<input type="checkbox"/>	T2 2Segment temperature	<input type="checkbox"/>	Electric Eye auto		
<input type="checkbox"/>	T3 3Segment temperature	<input type="checkbox"/>	time auto		
<input type="checkbox"/>	T4 4Segment temperature	<input type="checkbox"/>	Heater ON/OFF		
<input type="checkbox"/>	T5 5Segment temperature	<input checked="" type="checkbox"/>	Motor ON		
<input type="checkbox"/>	Oil lubricate	<input type="checkbox"/>	Auto run		
<input checked="" type="checkbox"/>	S11△ motor	<input type="checkbox"/>	S12 YMotor		
Machine run well				mold close slow	
Alarm	Input	Output	Key test	AD test	Servo alarm

- (6) Above delivery inspection pages are used for monitoring signals. If you want to inspect whether the delivery valve is ok or not manually without any actions, you can move the cursor to the delivery name which is waiting for your inspection, pressure enter button, then the delivery valve will come to work. Meanwhile the solid block in the scene shows the delivery of the signals.


★ Special explanation

All the input and output point pages in this instruction manual are subject to changes without notice. The inspection pages displayed on the computer should be correct and final.


Appendix 1:MS210 keyboard installation dimension Layout




Appendix 2:MS220/250 keyboard installation dimension Layout





Appendix 3: MS260 keyboard installation dimension Layout




Appendix 4: External dimensions for power supply case and transformer




Exterior dimensions and installation hole position drawings for main controller







Appendix 6: MS300 input and output Wiring Diagram




Appendix 7: MS500 input and output Wiring Diagram



Appendix 8 MS700 input and outputWiring Diagram




Appendix 9: Motor Electric-Heating Wiring Diagram (for reference only)




Appendix 10: Introduction of new type of patent double channel compensation linear sensor




Linear sensor wiring diagram see chart 1




图一



Normal power supply ideal output situation , see chart 2



Use V1V2 as output mark of this sensor ,see chart 2



Linear precision of single channel is basis

Comprehensive linear precision is 0.01% higher than single channel.

Features of double channel compensation linear transducer

The reason for digital bounce of traditional potentiometer type of displacement sensor is actual caused by fluctuations of supply voltage or measurement reference voltage or by these two elements. Traditional linear scale now can not solve the digital bounce problem generated by servo systems, but the double-path compensation type of displacement sensor is just designed for this problem.

And when input voltage of displacement sensor is risen or fallen, this $V1/V2$ value remain unchanged, namely this curve is unchanged. Then this curve which not change with voltage variation (in this example, voltage rise to 1 vdc or fall to 1 vdc is still reliable) and this decides the displacement sensor's shift. Even in a situation like voltage change causing by interference, can still reach 0.015mm stability. (take 350mm stroke as example) when stroke reach 250mm, the stability can still reach 0.10mm. These performances are two order of magnitudes higher than traditional displacement sensor which is first choice for precision injection molding machine. Use the new type of displacement sensor can solve once for all the problems such as injection measurement not correct, inaccurate of mold opening position or even cause damage to machine. As injection molding machine manufacturer to adopt the new type of displacement sensor can greatly reduce frequencies of malfunction and maintenance so as to lower maintenance service charge and to improve brand image.

This patent displacement sensor is with analog signal, simple structure, mechanical compatibility, high reliability, cheap cost and good adoptive to power supply, strong anti-interference to servo system.


Appendix 11:Magnetic suspension displacement sensor

Digital impulse output is the most economic can reach effect of anti-interference digital signal output. First controller will send start pulse to sensor. Sensor will issue stop pulse correspondingly based on magnetic pitch position. And controller can calculate the time difference between two groups pulses and then calculate the precision displacement value.




Installation of floating magnetic is very simple. Compare with captive magnetic, floating magnetic can demonstrate the advantage of non-contact sensing and eliminate wear of captive magnetic socket (Working distance between magnetic and working surface is 0.1--10mm)

Specification	Technology parameter
Order No	1830
Output	Digital pulse output
Measurement data	Linear displacement
Resolution	0.1/0.01/0.005mm
Power supply	+24Vdc(20.4-28.8Vdc)
Input protection	Polarity protection up to -30vdc, over voltage protection up to 36vdc.
Current consumption	50-150mA(based on stroke)
Insulation strength	500Vdc(DC ground to machine ground)
Repeatability	Full range<±0.005%
No-linearity	Full range<±0.01%(max +90 μm)
Update time	0.5ms up to 1200mm 0.5ms up to 1200mm 2ms up to 4800mm 5.0ms up to 7600mm
Working temperature	-40-75℃ humidity 90% non-condensing
Sealing	IP(with connector)
Vibration indicator	15g/10-2000Hz/IEC 68-2-6
EMC test	Radiation EN61000-6-3,anti-interferenceE N61000-6-2 E N61000-4-2/3/4/6



(See toward sensor outlet) Cable shield connects to connector shell and grounded at controller side.

P1	+24Vdc
P2	B output
P3	A output
P4	+0Vdc



Order No

1 8 3 0 X X X X X X

output

digital pulse output
(IP65 4pins connector)

mounting

1=42.5mm mounting
2=42.5mm isolation mounting
3=50mm mounting

Magnetic type

1=captive 3=die-casting
2=suspension 4=large suspension
effective stroke (mm)

0100	0130	0150	0175	0200	0225	0250
0275	0300	0360	0400	0425	0450	0500
0525	0550	0600	0650	0700	0750	0800
0875	0900	0950	1000	1100	1250	1350
1500	1600	1750	2000	2250	2500	2750
3000	3250	3500	4000	Accept custom		

Injection molding machine can use suspension type displacement transducer.

Installation of floating magnetic is very simple. Compare with captive magnetic, floating magnetic can demonstrate the advantage of non-contact sensing and eliminate wear of captive magnetic socket. Working distance between magnetic and working surface is 0.1--10mm.



Appendix 12 Product selection table

Mainframe selection chart

Mainframe model specification	MS300	MS500	MS700
Outline size	166X251	170X220	190X300
Input/output ports	28/25	32/27	27/28
Relay output ports	9	10	10
Temperature input	4	6	7
AD analog quantity input	6	6	3
AD analog quantity input	2	2	3
magnetic suspension ruler	0	1	0
DAC 0-1A output	3	3	3
DAC 0-10V output	2	2	4
I/O extension	8/22	8/22	8/22
Communication pattern	RS422/RS485/CAN	RS422/RS485/CAN	RS422/RS485/CAN
AD Sensor	0	4	4

Notice: E-ruler, magnetic suspension ruler use same AD input, while use it for magnetic suspension ruler, the E-ruler can not be used, same to double-path ruler.

Keyboard selection chart



Outline size	MS210	MS220	MS250	MS260
Model specification	210X470	260X470	260X470	300X510
CPU specification	A8/300M	A8/300M	A8/300M	A8/800M
LCD screen	7寸 800X480	7寸 800X480	8寸 1024X600	10寸 1024X600
Communication interface	RS422	RS422	RS422	RS422
Working temperature	-10~50℃	-10~50℃	-10~50℃	-10~50℃
Ethernet interface	100M	100M	100M	100M
Storage interface	USB	USB	USB	USB
Key life	200000times	200000times	200000times	200000times

Appendix 14:Product Guarantee Terms

Product Guarantee Terms

- I. Our guarantee services are provided by our after-sale service center of all offices all over China and cover all products sold by us.
- II. Our products carry out one-month 3-R service and two-year (one year for LCD screen) free repair service. Except otherwise specified by both parties, these periods shall start as of the date where the products are sold.
- III. Provided that they are used normally, in case of failures due to quality reason of the products, within the 3-R or free repair period, we will provide free repair or replacement for you.
- IV. Within the 3-R or free repair period, in any of the following circumstances, you will not be able to enjoy the 3-R service and free repair service:
 1. When the product is defective or damaged due to human factor or force majeure;
 2. When the product is damaged due to the installation and operation not conforming to the related regulations;
 3. When the product is damaged due to peripheral electric leakage or short during use;
 4. When the product is damaged due to being bumped by external force during use;
 5. When the product is repaired without permission or its bar code or serial number is torn or altered;
 6. When the product is used in the environment with high temperature and humidity and thus it is burnt due to overheat or damaged due to high damp.
- V. We undertake hereby that, if the domestic user needs after-sale services due to product quality, based on our service offices everywhere, we will repair the product within 24h if in the same city, within 48h if in the same province or not later than 72h if out of the same province to reach your place; if the overseas user needs such service, he can send the product back to us at its own cost and we will provide the desired repair.
- VI. In order to satisfy the individualized demand of the user, our products can provide software development package for secondary development; however, the user should bear all risks therefrom.
- VII. In case of failures during use, the user should inform us as soon as possible and then we will display our professional technicians for repair. It is not allowed to dismantle the product by the user without our permission; otherwise, it will be deemed that the user waives the right for free repair and any loss or product damage will be assumed by the user.
- VIII. The repair out of the free maintenance period will be charged. The failure of the same feature can enjoy 3-month free maintenance as of the completion of the first maintenance; however, the six circumstances mentioned in IV above will be excluded for free maintenance.
- IX. These Terms shall come into effect as of June 1, 2009. In the case where any terms before are inconsistent with these Terms, the latter shall prevail.
- X. We reserve the final right to interpret these Terms.